

**Switch & Socket**

[www.artdna-global.com](http://www.artdna-global.com)

86 STYLE CATALOGUE

**ART  
DNA**

International Switch Expert

ARTDNA Switches & Sockets



**ZHONGSHAN GAMDER ELECTRIC APPLIANCE CO.,LTD**

Addr: No.8-1 Middle of Industry Avenue, XiaoLan Town, ZhongShan,GuangDong, China.

Tel: 0086 760 2255 1677

Fax: 0086 760 2255 1960

E-mail: [artdnasales\\_01@gamder.cn](mailto:artdnasales_01@gamder.cn)

[www.artdna-global.com](http://www.artdna-global.com)



E-Catalogue

**86 STYLE CATALOGUE**

# ARTDNA CONTENTS

About ARTDNA	3
Marketing	5
Qualification and Certificates	7
ARTDNA Concept	8
Products Structure	9
V23 series	11
V12 series	17
A77 series	23
A69 series	29
A66 series	36
A68 series	43
A38 series	49
D3 series	55
A63 series	61
E3 series	67
B3 series	74





# About ARTDNA

The ARTDNA brand was founded in 2012 and is one of the two major brands of Zhongshan Gamder Electric Appliance Co., Ltd. Since its establishment, the ARTDNA brand has a strong sense of modernity and an international mission. Through unremitting efforts, in 2014, ARTDNA created a new category representing one of the development directions of electrical products: CONJOIN SWITCHES.

In 2019, with the rise of intelligent development of electrical products, ARTDNA began to deploy intelligent control, and promote the "intelligent optoelectronic integration" project according to the development and demand of the market.

In terms of intelligent control, ARTDNA cooperates to develop and produce a variety of intelligent switches, intelligent dimming, intelligent touch screens, gateways and intelligent lighting drivers, and has established in-depth cooperation with many intelligent ecological enterprises in the industry, and thus won the "Guangdong Province Famous Brand Product" and other honors.





# Market Internationalization



• ARTDNA Showroom Malaysia




• ARTDNA Showroom Thailand



• ARTDNA Showroom Vietnam



• ARTDNA Showroom Iraq



• Select 2022 Bangkok



• Canton Fair Guangzhou



• Lighting Fair Hongkong



• MEE Dubai



• Hilton Garden Inn Thailand



• Moty Hotel Malaysia



• Pistachio Hotel Vietnam



• MBR City U.A.E



# Qualification And Certificates



• ISO9001 ISO 14001 Certification



• SQM Certificate



• ASTA Certificate



• CE Certification



• CB Certificate



• TIS Certificate



• Invention Patent



• Practical Patent



• Design Patent



“He is a British Designer with the best power for inspiration”  
— Sunday Times, Britain

Michael Young

ARTDNA Chief Design Adviser

An Outstanding International Industrial Designer

A Judge of Germany IF Product Design Award in 2010/2013

The Creative Director of 100% Tokyo Design Competition in 2007, 2008 and 2009


.....

*Michael Young*






# Products Structure



Switch



Socket



# V23 SERIES

- Frameless Large Panel Design
- High Current Load Design For Larger LED Loading
- Large Size Sliding Terminal For Easier Wiring
- Multiple materials optional
- Switch with LED Indicator



**V23-K01A V23-K01B**  
10AX 1 Gang Switch

PACK: 80pcs 1



**V23-K02A V23-K02B**  
10AX 2 Gang Switch

PACK: 80pcs 2



**V23-K03A V23-K03B**  
10AX 3 Gang Switch

PACK: 80pcs 3



**V23-K04A V23-K04B**  
10AX 4 Gang Switch

PACK: 80pcs 4



**V23-K16**  
10A Doorbell Switch

PACK: 80pcs 5



**V23-K19**  
10AX 1 Gang Intermediate Switch

PACK: 80pcs 6



**V23-K20**  
10AX 2 Gang Intermediate Switch

PACK: 80pcs 7



**V23-BK01A V23-BK01B**  
10AX 1 Gang Full-Flat with LED Indicator Switch

PACK: 80pcs 8



**V23-BK02A V23-BK02B**  
10AX 2 Gang Full-Flat with LED Indicator Switch

PACK: 80pcs 9



**V23-BK03A V23-BK03B**  
10AX 3 Gang Full-Flat with LED Indicator Switch

PACK: 80pcs 10



**V23-BK04A V23-BK04B**  
10AX 4 Gang Full-Flat with LED Indicator Switch

PACK: 80pcs 11



**V23-K77**  
10AX 1 Gang Full-Flat with LED Indicator Intermediate Switch

PACK: 80pcs 12



**V23-P01**  
Single Blank Plate

PACK: 200pcs 13



**V23-K45 V23-K46**  
5A/13A Switched Fused Connection Unit with Neon

PACK: 80pcs 14



**V23-K30**  
20A Double Pole Switch with Neon

PACK: 80pcs 15



**V23-K50-2**  
45A Double Pole Switch with LED Indicator

PACK: 80pcs 16



**V23-C11**  
13A BS Socket

PACK: 80pcs 17



**V23-C29**  
13A BS Socket with Switch

PACK: 80pcs 18



**V23-C12**  
13A Single Switched Socket with Neon

PACK: 80pcs 19



**V23-C31**  
13A BS Socket with DP Switch

PACK: 80pcs 20





**V23-C32**  
13A Single Socket with DP Switch & Neon  
PACK: 80pcs 21



**V23-C29E16**  
13A BS Switched Socket with 2.1A USB Charger  
PACK: 60pcs 22



**V23-C31E16**  
13A Double Pole BS Switched Socket with 2.1A USB Charger  
PACK: 60pcs 23



**V23-JAC28**  
16A 1 Gang Euro-American Socket with Switch  
PACK: 80pcs 24



**V23-E24-2**  
3.1A Double USB Charger  
PACK: 60pcs 41



**V23-E31**  
20W Type A+C USB Charger  
PACK: 60pcs 42



**V23-E33**  
65W Type A+C USB Charger  
PACK: 60pcs 43



**V23-P37**  
45A Flex Outlet  
PACK: 60pcs 44



**V23-C28K**  
16A Switched Euro & American Socket  
PACK: 80pcs 25



**V23-C28E24**  
16A Euro & American Socket with 2 Ports USB Charge  
PACK: 60pcs 26



**V23-C28E32**  
16A Euro & American Socket with Type A+C USB Charge  
PACK: 60pcs 27



**V23-C42**  
16A Double Euro & American Socket  
PACK: 80pcs 28



**V23-P38**  
25A Flex Outlet  
PACK: 80pcs 45



**V23-E01**  
Telephone Socket  
PACK: 80pcs 46



**V23-E02**  
Computer Socket(CAT.6)  
PACK: 80pcs 47



**V23-E03**  
Single TV Socket  
PACK: 80pcs 48



**V23-C18**  
16A 2P + E German Socket  
PACK: 80pcs 29



**V23-C22**  
16A 2P+E French Socket  
PACK: 80pcs 30



**V23-C23**  
16A 2P European Socket  
PACK: 80pcs 31



**V23-C17**  
15A 3 Round Pin Socket with Switch  
PACK: 80pcs 32



**V23-2E01 V23-2E02**  
Double Telephone Socket  
Double Computer Socket (CAT.6)  
PACK: 80pcs 49



**V23-E0102**  
Telephone & Computer Socket (CAT.6)  
PACK: 80pcs 50



**V23-2E03**  
Double TV Socket  
PACK: 80pcs 51



**V23-E06**  
Single Satellite Socket  
PACK: 80pcs 52



**V23-C38**  
15A 3 Round Pin Switched Socket with LED Indicator  
PACK: 80pcs 33



**V23-C06**  
16A 2 Pin & 3 Pin Universal Socket  
PACK: 80pcs 34



**V23-C36**  
16A 3 Pin Universal Socket with Switch  
PACK: 80pcs 35



**V23-C37**  
16A 3 Pin Universal Switched Socket with LED Indicator  
PACK: 80pcs 36



**V23-E0608**  
TV & Satellite Socket  
PACK: 80pcs 53



**V23-E0103 V23-E0203**  
Telephone & TV Socket  
Computer & TV Socket (CAT.6)  
PACK: 80pcs 54



**V23-E0206**  
Computer & Satellite Socket(CAT6)  
PACK: 80pcs 55



**V23-2E07**  
2 Gang Speaker Outlet  
PACK: 80pcs 56



**V23-C45**  
16A Switched Universal Socket with Night Light  
PACK: 80pcs 37



**V23-C06E29**  
2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger  
PACK: 60pcs 38



**V23-C06E24**  
2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger  
PACK: 60pcs 39



**V23-C06E32**  
2 Pin & 3 Pin Universal Socket with Type A+C USB Charger  
PACK: 60pcs 40



**V23-K22 V23-K24**  
Background/General Speaker  
Voice Dimmer Switch  
PACK: 60pcs 57



**V23-K09 V23-K10**  
300W Light Dimmer Switch  
630W Light Dimmer Switch  
PACK: 60pcs 58



**V23-K86**  
1000W Two Way Push Dimmer Switch  
PACK: 60pcs 59



**V23-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 60pcs 60





**V23-K11**  
300W Fan Dimmer Switch  
PACK: 60pcs 61



**V23-K88**  
300W Two Way Push Fan Dimmer Switch  
PACK: 60pcs 62



**V23-K93**  
100W Step Fan Dimmer Switch  
PACK: 40pcs 63



**V23-K12**  
Air Control Dimmer Switch  
PACK: 60pcs 64



**V23-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch  
PACK: 80pcs 81



**V23-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch  
PACK: 80pcs 82



**V23-C34**  
10VA 115V~ / 10A 230V~ Shaver Socket  
PACK: 16pcs 83



**V23-C08**  
3X6 Shaver Socket  
PACK: 10pcs 84



**V23-K01BK09**  
300W Light Dimmer With Two Way Rocker Switch  
PACK: 60pcs 65



**V23-K01BK11**  
300W Fan Dimmer With Two Way Rocker Switch  
PACK: 60pcs 66



**V23-K25**  
Acoustooptic Controlled Switch with Time Delay  
PACK: 80pcs 67



**V23-K26**  
Touch Switch with Time Delay  
PACK: 80pcs 68



**V23-C13**  
13A Twin BS Socket  
PACK: 50pcs 85



**V23-C30**  
13A Twin BS Socket with Switch  
PACK: 50pcs 86



**V23-C14**  
13A Twin BS Socket with Switch & LED Indicator  
PACK: 50pcs 87



**V23-C39**  
13A Twin BS Socket with DP Switch  
PACK: 50pcs 88



**V23-K23**  
PIR Switch  
PACK: 60pcs 69



**V23-K85**  
PIR Floor Light  
PACK: 80pcs 70



**V23-K36**  
LED Foot Light  
PACK: 80pcs 71



**V23-K37**  
1W Buzzer  
PACK: 80pcs 72



**V23-C40**  
13A Twin BS Socket with DP Switch & LED Indicator  
PACK: 50pcs 89



**V23-C30E24**  
13A Twin Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 90



**V23-C14E24**  
13A Twin Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 91



**V23-C39E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 92



**V23-K31**  
3A Alarm Switch  
PACK: 80pcs 73



**V23-K17**  
2A Bell Switch with "DO NOT DISTURB" Indicator  
PACK: 80pcs 74



**V23-K18**  
2A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator  
PACK: 80pcs 75



**V23-K21**  
2A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator  
PACK: 80pcs 76



**V23-C40E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 93



**V23-C43**  
16A Twin Universal Switched Socket  
PACK: 50pcs 94



**V23-C43E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 95



**V23-C44**  
16A Twin Universal Switched Socket with Neon  
PACK: 50pcs 96



**V23-K15**  
16A Key Card Switch  
PACK: 60pcs 77



**V23-K43**  
16A Low Frequency Key Card Switch  
PACK: 60pcs 78



**V23-K44**  
16A High Frequency Key Card Switch  
PACK: 60pcs 79



**V23-K96**  
"DO NOT DISTURB" Switch  
PACK: 80pcs 80



**V23-C44E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 97



**V23-C26**  
45A Cooker Unit  
PACK: 50pcs 98



**V23-K90**  
147 45A DP Switch  
PACK: 50pcs 99



**V23-P28**  
Double Blank Plate  
PACK: 160pcs 100



# V12 SERIES

- Colorful Metal Stamping Logo
- Crystal Texture Without Borders Large Panel
- High Current Load Design For Larger LED Loading
- Large Size Sliding Terminal For Easier Wiring



Grey



Coffee



**V12-K01A V12-K01B**  
10AX 1 Gang Switch

PACK: 80pcs 1



**V12-K02A V12-K02B**  
10AX 2 Gang Switch

PACK: 80pcs 2



**V12-K03A V12-K03B**  
10AX 3 Gang Switch

PACK: 80pcs 3



**V12-K04A V12-K04B**  
10AX 4 Gang Switch

PACK: 80pcs 4



**V8 -K16**  
10A Doorbell Switch

PACK: 80pcs 5



**V12-K19**  
10AX 1 Gang Intermediate Switch

PACK: 80pcs 6



**V12-K20**  
10AX 2 Gang Intermediate Switch

PACK: 80pcs 7



**V12-P01**  
Single Blank Plate

PACK: 200pcs 8



**V12-K45 V12-K46**  
5A/13A Switched Fused Connection Unit with Neon

PACK: 80pcs 9



**V12-K30**  
20A Double Pole Switch with Neon

PACK: 80pcs 10



**V12-K50**  
45A Double Pole Switch with LED Indicator

PACK: 80pcs 11



**V12-C11**  
13A BS Socket

PACK: 80pcs 12



**V12-C29-3**  
13A BS Socket with Switch

PACK: 80pcs 13



**V12-C12-3**  
13A Single Switched Socket with Neon

PACK: 80pcs 14



**V12-C31**  
13A BS Socket with DP Switch

PACK: 80pcs 15



**V12-C32**  
13A Single Socket with DP Switch & Neon

PACK: 80pcs 16



**V12-C29E16**  
13A BS Switched Socket with 2.1A USB Charger

PACK: 60pcs 17



**V12-C31E16**  
13A Double Pole BS Switched Socket with 2.1A USB Charger

PACK: 60pcs 18



**V12-JAC28**  
16A 1 Gang Euro-American Socket with Switch

PACK: 80pcs 19



**V12-C28K**  
16A Switched Euro & American Socket

PACK: 80pcs 20





**V12-C28E24**  
16A Euro & American Socket  
with 2 Ports USB Charge  
PACK: 60pcs 21



**V12-C28E32**  
16A Euro & American Socket  
with Type A+C USB Charge  
PACK: 60pcs 22



**V12-C18**  
16A 2P + E German Socket  
PACK: 80pcs 23



**V12-C22**  
16A 2P+E French Socket  
PACK: 80pcs 24



**V12-E02**  
Computer Socket(CAT.6)  
PACK: 80pcs 41



**V12-E03**  
Single TV Socket  
PACK: 80pcs 42



**V12-2E01 V12-2E02**  
Double Telephone Socket  
Double Computer Socket (CAT.6)  
PACK: 80pcs 43



**V12-E0102**  
Telephone &Computer Socket  
(CAT.6)  
PACK: 80pcs 44



**V12-C23**  
16A 2P European Socket  
PACK: 80pcs 25



**V12-C17**  
15A 3 Round Pin Switched  
Socket  
PACK: 80pcs 26



**V12-C38**  
15A 3 Round Pin Switched Socket  
with LED Indicator  
PACK: 80pcs 27



**V12-C06**  
16A 2 Pin & 3 Pin Universal Socket  
PACK: 80pcs 28



**V12-2E03**  
Double TV Socket  
PACK: 80pcs 45



**V12-E06**  
Single Satellite Socket  
PACK: 80pcs 46



**V12-E0608**  
TV & Satellite Socket  
PACK: 80pcs 47



**V12-E0103 V12-E0203**  
Telephone &TV Socket  
Computer & TV Socket (CAT.6)  
PACK: 80pcs 48



**V12-C36**  
16A 3 Pin Universal Socket  
with Switch  
PACK: 80pcs 29



**V12-C37**  
16A 3 Pin Universal Switched Socket  
with LED Indicator  
PACK: 80pcs 30



**V12-C45**  
16A Switched Universal Socket  
with Night Light  
PACK: 80pcs 31



**V12-C06E29**  
2 Pin & 3 Pin Universal Socket  
with 2.1A Double USB Charger  
PACK: 60pcs 32



**V12-E0206**  
Computer & Satellite Socket(CAT6)  
PACK: 80pcs 49



**V12-2E07**  
2 Gang Speaker Outlet  
PACK: 80pcs 50



**V12-K22 V12-K24**  
Background/General Speaker  
Voice Dimmer Switch  
PACK: 60pcs 51



**V12-K09 V12-K10**  
300W Light Dimmer Switch  
630W Light Dimmer Switch  
PACK: 60pcs 52



**V12-C06E24**  
2 Pin & 3 Pin Universal Socket  
with 3.4A Double USB Charger  
PACK: 60pcs 33



**V12-C06E32**  
2 Pin & 3 Pin Universal Socket  
with Type A+C USB Charger  
PACK: 60pcs 34



**V12-E24-2**  
3.1A Double USB Charger  
PACK: 60pcs 35



**V12-E31**  
20W Type A+C USB Charger  
PACK: 60pcs 36



**V12-K86**  
1000W Two Way Push Dimmer  
Switch  
PACK: 60pcs 53



**V12-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 60pcs 54



**V12-K11**  
300W Fan Dimmer Switch  
PACK: 60pcs 55



**V12-K88**  
300W Two Way Push Fan  
Dimmer Switch  
PACK: 60pcs 56



**V12-E33**  
65W Type A+C USB Charger  
PACK: 60pcs 37



**V12-P37**  
45A Flex Outlet  
PACK: 60pcs 38



**V12-P38**  
25A Flex Outlet  
PACK: 80pcs 39



**V12-E01**  
Telephone Socket  
PACK: 80pcs 40



**V12-K93**  
100W Step Fan Dimmer Switch  
PACK: 40pcs 57



**V12-K12**  
Air Control Dimmer Switch  
PACK: 60pcs 58



**V12-K01BK09**  
300W Light Dimmer With  
Two Way Rocker Switch  
PACK: 60pcs 59



**V12-K01BK11**  
300W Fan Dimmer With Two  
Way Rocker Switch  
PACK: 60pcs 60





**V12-K25**  
Acousto-optic Controlled Switch  
with Time Delay  
PACK: 80pcs 61



**V12-K26**  
Touch Switch with Time Delay  
PACK: 80pcs 62



**V12-K23**  
PIR Switch  
PACK: 60pcs 63



**V12-K85**  
PIR Floor Light  
PACK: 60pcs 64



**V12-C14**  
13A Twin BS Socket with  
Switch & LED Indicator  
PACK: 50pcs 81



**V12-C39**  
13A Twin BS Socket with DP Switch  
PACK: 50pcs 82



**V12-C40**  
13A Twin BS Socket with DP  
Switch & LED Indicator  
PACK: 50pcs 83



**V12-C30E24**  
13A Twin Switched Socket with  
2 Ports USB Charger  
PACK: 40pcs 84



**V12-K36**  
LED Foot Light  
PACK: 80pcs 65



**V12-K37**  
1W Buzzer  
PACK: 80pcs 66



**V12-K31**  
3A Alarm Switch  
PACK: 80pcs 67



**V12-K17**  
2A Bell Switch with "DO NOT  
DISTURB" Indicator  
PACK: 80pcs 68



**V12-C14E24**  
13A Twin Switched Socket with  
2 Ports USB Charger & Neon  
PACK: 40pcs 85



**V12-C39E24**  
13A Twin DP Switched Socket with  
2 Ports USB Charger  
PACK: 40pcs 86



**V12-C40E24**  
13A Twin DP Switched Socket with  
2 Ports USB Charger & Neon  
PACK: 40pcs 87



**V12-C43**  
16A Twin Universal Switched Socket  
PACK: 50pcs 88



**V12-K18**  
2A Bell Switch with "DO NOT DISTURB"  
& "MAKE UP ROOM" Indicator  
PACK: 80pcs 69



**V12-K21**  
2A Bell Switch with "DO NOT DISTURB"  
& "MAKE UP ROOM" & "PLEASE WAIT"  
Indicator  
PACK: 80pcs 70



**V12-K15**  
16A Key Card Switch  
PACK: 60pcs 71



**V12-K43**  
16A Low Frequency  
Key Card Switch  
PACK: 60pcs 72



**V12-C43E24**  
16A Twin Universal Switched Socket  
with 2 Ports USB Charger  
PACK: 40pcs 89



**V12-C44**  
16A Twin Universal Switched Socket  
with Neon  
PACK: 50pcs 90



**V12-C44E24**  
16A Twin Universal Switched Socket  
with 2 Ports USB Charger & Neon  
PACK: 40pcs 91



**V12-C26**  
45A Cooker Unit  
PACK: 50pcs 92



**V12-K44**  
16A High Frequency  
Key Card Switch  
PACK: 60pcs 73



**V12-K96**  
"DO NOT DISTURB" Switch  
PACK: 80pcs 74



**V12-K97**  
"DO NOT DISTURB" & "MAKE  
UP ROOM" Switch  
PACK: 80pcs 75



**V12-K98**  
"DO NOT DISTURB" & "MAKE UP  
ROOM" & "PLEASE WAIT" Switch  
PACK: 80pcs 76



**V12-K90**  
147 45A DP Switch  
PACK: 50pcs 93



**V12-P28**  
Double Blank Plate  
PACK: 160pcs 94



**V12-C34**  
10VA 115V~ / 10A 250V~  
Shaver Socket  
PACK: 16pcs 77



**V12-C08**  
3X6 Shaver Socket  
PACK: 10pcs 78



**V12-C13**  
13A Twin BS Socket  
PACK: 50pcs 79




**V12-C30**  
13A Twin BS Socket with  
Switch  
PACK: 50pcs 80



# A77 SERIES

- Modular products, freely assembled
- A variety of color modules, a variety of materials frame
- Purely flat switch with LED indicator and rocker switch optional



## Multicolor Frames-1

### Thin Aluminum Series

	<b>A77-P24</b>	86 Frame	PACK: 200 pcs
	<b>A77-P19</b>	286 Frame	PACK: 120 pcs
	<b>A77-P20</b>	386 Frame	PACK: 60 pcs
	<b>A77-P21</b>	486 Frame	PACK: 50 pcs
	<b>A77-P29</b>	586 Frame	PACK: 40 pcs

	<b>A77-P23</b>	2 Gang Frame	PACK: 100 pcs
---	----------------	--------------	---------------

### Space Grey Aluminum Series

	<b>A78-P24A</b>	86 Frame	PACK: 200 pcs
	<b>A78-P19A</b>	286 Frame	PACK: 100 pcs
	<b>A78-P20A</b>	386 Frame	PACK: 60 pcs
	<b>A78-P21A</b>	486 Frame	PACK: 50 pcs
	<b>A78-P29A</b>	586 Frame	PACK: 40 pcs

	<b>A78-P23A</b>	2 Gang Frame	PACK: 100 pcs
---	-----------------	--------------	---------------

### Rose Golden Aluminum Series

	<b>A78-P24B</b>	86 Frame	PACK: 200 pcs
	<b>A78-P19B</b>	286 Frame	PACK: 100 pcs
	<b>A78-P20B</b>	386 Frame	PACK: 60 pcs
	<b>A78-P21B</b>	486 Frame	PACK: 50 pcs
	<b>A78-P29B</b>	586 Frame	PACK: 40 pcs

	<b>A78-P23B</b>	2 Gang Frame	PACK: 100 pcs
---	-----------------	--------------	---------------

### Champagne Golden Aluminum Series

	<b>A78-P24A</b>	86 Frame	PACK: 200 pcs
	<b>A78-P19A</b>	286 Frame	PACK: 100 pcs
	<b>A78-P20A</b>	386 Frame	PACK: 60 pcs
	<b>A78-P21A</b>	486 Frame	PACK: 50 pcs
	<b>A78-P29A</b>	586 Frame	PACK: 40 pcs

	<b>A78-P23A</b>	2 Gang Frame	PACK: 100 pcs
---	-----------------	--------------	---------------

### White Crystal Glass Series

	<b>A78-P24F</b>	86 Frame	PACK: 200 pcs
	<b>A78-P19F</b>	286 Frame	PACK: 100 pcs
	<b>A78-P20F</b>	386 Frame	PACK: 60 pcs
	<b>A78-P21F</b>	486 Frame	PACK: 50 pcs
	<b>A78-P29F</b>	586 Frame	PACK: 40 pcs

	<b>A78-P23F</b>	2 Gang Frame	PACK: 100 pcs
---	-----------------	--------------	---------------

### Black Crystal Glass Series

	<b>A78-P24F</b>	86 Frame	PACK: 200 pcs
	<b>A78-P19F</b>	286 Frame	PACK: 100 pcs
	<b>A78-P20F</b>	386 Frame	PACK: 60 pcs
	<b>A78-P21F</b>	486 Frame	PACK: 50 pcs
	<b>A78-P29F</b>	586 Frame	PACK: 40 pcs

	<b>A78-P23F</b>	2 Gang Frame	PACK: 100 pcs
---	-----------------	--------------	---------------



# Multicolor Frames-2

## Brushed Stainless Series

	<b>A77-P24A</b>	86 Frame	PACK: 200 pcs
	<b>A77-P19A</b>	286 Frame	PACK: 120 pcs
	<b>A77-P20A</b>	386 Frame	PACK: 60 pcs
	<b>A77-P21A</b>	486 Frame	PACK: 50 pcs
	<b>A77-P29A</b>	586 Frame	PACK: 40 pcs

## Mirror Stainless Series
















	<b>A77-P24B</b>	86 Frame	PACK: 200 pcs
	<b>A77-P19B</b>	286 Frame	PACK: 120 pcs
	<b>A77-P20B</b>	386 Frame	PACK: 60 pcs
	<b>A77-P21B</b>	486 Frame	PACK: 50 pcs
	<b>A77-P29B</b>	586 Frame	PACK: 40 pcs

## Plastic Champagne Series


























	<b>A77-P24D</b>	86 Frame	PACK: 320 pcs
	<b>A77-P19D</b>	286 Frame	PACK: 160 pcs
	<b>A77-P20D</b>	386 Frame	PACK: 72 pcs
	<b>A77-P21D</b>	486 Frame	PACK: 60 pcs
	<b>A77-P29D</b>	586 Frame	PACK: 48 pcs

## Plastic Silver Series

	<b>A77-P24D</b>	86 Frame	PACK: 320 pcs
	<b>A77-P19D</b>	286 Frame	PACK: 160 pcs
	<b>A77-P20D</b>	386 Frame	PACK: 72 pcs
	<b>A77-P21D</b>	486 Frame	PACK: 60 pcs
	<b>A77-P29D</b>	586 Frame	PACK: 48 pcs

	<b>A77-P01</b>	Single Blank	PACK:384 pcs	16
	<b>A77-K45 A77-K46</b>	5A/13A Switched Fused Connection Unit with Neon	PACK:160 pcs	17
	<b>A77-K30</b>	20A Double Pole Switch with Neon	PACK:160 pcs	18
	<b>A77-K50-2</b>	45A Double Pole Switch with LED Indicator	PACK:160 pcs	19
	<b>A77-C11</b>	13A BS Socket	PACK: 160pcs	20
	<b>A77-C29-3</b>	13A BS Socket with Switch	PACK:160 pcs	21
	<b>A77-C12-3</b>	BS Socket with Switch & LED Indicator	PACK:160 pcs	22
	<b>A77-C31-2</b>	13A Single Socket with DP Switch	PACK: 160pcs	23
	<b>A77-C32-2</b>	13A Single Socket with DP Switch & Neon	PACK: 160pcs	24
	<b>A77-C29E16</b>	13A BS Switched Socket with 2.1A USB Charger	PACK: 96 pcs	25
	<b>A77-C31E16</b>	13A Double Pole BS Switched Socket with 2.1A USB Charger	PACK: 96 pcs	26
	<b>A77-JAC28</b>	16A 1 Gang Euro-American Socket with Switch	PACK: 160pcs	27
	<b>A77-C28K</b>	16A Switched Euro & American Socket Module	PACK:160 pcs	28
	<b>A77-C28E24</b>	16A Euro & American Socket with 2 Ports USB Charge Module	PACK: 96 pcs	29
	<b>A77-C28E32</b>	16A Euro & American Socket with Type A+C USB Charge Module	PACK: 96 pcs	30

# Modules

	<b>A77-K01A-2 A77-K01B-2</b>	10AX 1 Gang Switch Rocker	PACK: 160pcs	1
	<b>A77-K02A-2 A77-K02B-2</b>	10AX 2 Gang Switch Rocker	PACK: 160pcs	2
	<b>A77-K03A-2 A77-K03B-2</b>	10AX 3 Gang Switch Rocker	PACK: 160pcs	3
	<b>A77-K04A-2 A77-K04B-2</b>	10AX 4 Gang Switch Rocker	PACK: 160pcs	4
	<b>A77-K16</b>	10A Doorbell Switch	PACK:160 pcs	5
	<b>A77-K1A A77-K1B</b>	10AX 1 Gang Full-Flat Switch with LED Indicator	PACK:160 pcs	6
	<b>A77-K2A A77-K2B</b>	10AX 2 Gang Full-Flat Switch with LED Indicator	PACK: 160pcs	7
	<b>A77-K3A A77-K3B</b>	10AX 3 Gang Full-Flat Switch with LED Indicator	PACK: 160pcs	8
	<b>A77-K16</b>	10A 1 Gang Retractive Switch	PACK:160 pcs	9
	<b>A77-K28</b>	10A 2 Gang Retractive Switch	PACK:160 pcs	10
	<b>A77-C38</b>	15A 3 Round Pin Switched Socket with LED Indicator	PACK:160 pcs	36
	<b>A77-C06</b>	16A 2 Pin & 3 Pin Universal Socket	PACK:160 pcs	37
	<b>A77-C36</b>	16A 3 Pin Universal Socket with Switch	PACK:160 pcs	38
	<b>A77-C37</b>	16A 3 Pin Universal Switched Socket with LED Indicator Module	PACK:160 pcs	39
	<b>A77-C45</b>	16A Switched Universal Socket with Night Light	PACK: 96 pcs	40
	<b>A77-K51</b>	DC 12V 1 Gang Switch with LED Indicator	PACK:160 pcs	11
	<b>A77-K52</b>	DC 12V 2 Gang Switch with LED Indicator	PACK: 160 pcs	12
	<b>A77-K53</b>	DC 12V 3 Gang Switch with LED Indicator	PACK:160 pcs	13
	<b>A77-K19-2</b>	10AX 1 Gang Intermediate Switch Module	PACK:160 pcs	14
	<b>A77-K20-2</b>	10AX 2 Gang Intermediate Switch Module	PACK:160 pcs	15
	<b>A77-C06E29</b>	2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger	PACK:96 pcs	41
	<b>A77-C06E24</b>	16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger	PACK:96 pcs	42
	<b>A77-C06E32</b>	2 Pin & 3 Pin Universal Socket with Type A+C USB Charger Module	PACK: 96 pcs	43
	<b>A77-E24-2</b>	3.1A Double USB Charger Module	PACK: 96 pcs	44
	<b>A77-E31</b>	20W Type A+C USB Charger	PACK: 96 pcs	45





**A77-E33**  
65W Type A+C USB Charger  
PACK: 96 pcs 46



**A77-P37**  
45A Flex outlet  
PACK: 96 pcs 47



**A77-P38**  
25A Flex outlet  
PACK:160 pcs 48



**A77-E01**  
Single Telephone Socket  
PACK:160 pcs 49



**A77-E02**  
Single Computer Socket  
PACK:160 pcs 50



**A77-K37**  
1W Buzzer  
PACK:160 pcs 76



**A77-K31**  
3A Alarm Switch  
PACK:160 pcs 77



**A77-K17**  
2A Bell Swith with "DO NOT DISTURB" Indicator  
PACK:160 pcs 78



**A77-K18**  
2A Bell Swith with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator  
PACK:160 pcs 79



**A77-K21**  
2A Bell Swith with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator  
PACK:160 pcs 80



**A77-E03**  
Single TV Socket  
PACK:160 pcs 51



**A77-2E01**  
Double Telephone Socket  
PACK:160 pcs 52



**A77-2E02**  
Double Computer Socket  
PACK:160 pcs 53



**A77-E0102**  
Telephone & Computer Socket  
PACK:160 pcs 54



**A77-E06**  
Satellite Socket  
PACK:160 pcs 55



**A77-K15**  
16A KeyCard Switch  
PACK:96 pcs 81



**A77-K43**  
16A Low Frequency KeyCard Switch  
PACK:96 pcs 82



**A77-K44**  
16A High Frequency KeyCard Switch  
PACK:96 pcs 83



**A77-K96**  
"DO NOT DISTURB" Switch Module  
PACK:160 pcs 84



**A77-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch Module  
PACK:160 pcs 85



**A77-E0608**  
TV & Satellite Socket  
PACK:160 pcs 56



**A77-E0103**  
Telephone & TV Socket  
PACK:160 pcs 57



**A77-E0203**  
Computer & TV Socket  
PACK:160 pcs 58



**A77-E0206**  
Computer & Satellite Socket Module  
PACK:160 pcs 59



**A77-2E07**  
2 Gang Speaker Outlet  
PACK:160 pcs 60




**A77-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch Module  
PACK:160 pcs 86



**A77-C34**  
10VA 115V~/ 10A 230V~ Shaver Socket  
PACK: 16 pcs 87



**A77-C08**  
Shaver Socket  
PACK: 10 pcs 88



**A77-C13-2**  
13A Twin BS Socket  
PACK: 50pcs 89



**A77-C30-2**  
13A Twin BS Socket with Switch  
PACK: 50pcs 90



**A77-K22** **A77-K24**  
Background/General Speaker  
PACK: 96 pcs 61



**A77-K09** **A77-K10**  
300W Light Dimmer  
PACK: 96pcs 62



**A77-K86**  
1000W 2 Way Light Dimmer Switch  
PACK: 96pcs 63



**A77-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 96 pcs 64



**A77-K11**  
300W Fan Dimmer Switch  
PACK:96 pcs 65



**A77-C14-2**  
13A Twin BS Socket with Switch & LED Indicator  
PACK: 50pcs 91



**A77-C39**  
13A Twin BS Socket with DP Switch  
PACK: 50pcs 92



**A77-C40**  
13A Twin BS Socket with DP Switch & LED Indicator  
PACK: 50pcs 93



**A77-C30E24**  
13A Twin Switched Socket with 2 Ports USB Charger  
PACK: 40 pcs 94



**A77-C14E24**  
13A Twin Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40 pcs 95



**A77-K88**  
300W Two Way Push Fan Dimmer Switch  
PACK: 96pcs 66



**A77-K93**  
100W Step Fan Dimmer Switch  
PACK: 96 pcs 67



**A77-K12**  
Air Control Dimmer Switch  
PACK: 96 pcs 68



**A77-K01BK09**  
300W Light Dimmer With Two Way Rocker Switch  
PACK: 96 pcs 69



**A77-K01BK11**  
300W Fan Dimmer With Two Way Rocker Switch  
PACK: 96 pcs 70



**A77-C39E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger  
PACK: 40 pcs 96



**A77-C40E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40 pcs 97



**A77-C43**  
16A Twin Universal Switched Socket  
PACK: 50 pcs 98



**A77-C43E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger  
PACK: 40 pcs 99



**A77-C44**  
16A Twin Universal Switched Socket with Neon  
PACK: 50 pcs 100



**A77-K25**  
45-100W Voice Activated & Light Sensor Switch with Time Delay  
PACK:160 pcs 71



**A77-K26**  
Touch Switch with Time Delay  
PACK:160 pcs 72



**A77-K23**  
65-100W PIR Switch  
PACK:96 pcs 73



**A77-K85**  
PIR Foot Light  
PACK:160 pcs 74



**A77-K36**  
0.7W LED Footlight  
PACK:160 pcs 75



**A77-C44E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40 pcs 101



**A77-C26**  
45A Cooker Unit  
PACK: 50pcs 102



**A77-K90**  
147 45A DP Switch  
PACK: 50 pcs 103



**A77-P28**  
Double Blank Module  
PACK: 400pcs 104



# A69 SERIES

- 1.0mm Brushed metal panel
- 304 stainless steel
- Purely flat switch with LED indicator and rocker switch optional



**A69-BK01A A69-BK01B**  
16AX 1 Gang Switch Rocker

PACK: 80pcs 1



**A69-BK02A A69-BK02B**  
16AX 2 Gang Switch Rocker

PACK: 80pcs 2



**A69-BK03A A69-BK03B**  
16AX 3 Gang Switch Rocker

PACK: 80pcs 3



**A69-BK04A A69-BK04B**  
10AX 4 Gang Switch Rocker

PACK: 80pcs 4



**E9-K16**  
16A Doorbell Switch

PACK: 80pcs 5



**A69-BK19**  
10AX 1 Gang Intermediate Switch

PACK: 80pcs 6




**A69-BK20**  
10AX 2 Gang Intermediate Switch

PACK: 80pcs 7



**A69-BK1A A69-BK1B**  
10AX 1 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 8



**A69-BK2A A69-BK2B**  
10AX 2 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 9



**A69-BK3A A69-BK3B**  
10AX 3 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 10



**A69-BK4A A69-BK4B**  
10AX 4 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 11



**K9-BK1A K9-BK1B**  
10AX 1 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 12



**K9-BK2A K9-BK2B**  
10AX 2 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 13



**K9-BK3A K9-BK3B**  
10AX 3 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 14



**K9-BK4A K9-BK4B**  
10AX 4 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 15



**K9-K77**  
10AX 1 Gang Intermediate Full-Flat Switch with LED Indicator

PACK: 80pcs 16



**A69-P01**  
Single Blank Plate

PACK: 200pcs 17



**A69-K45/K46**  
5A/13A Switched Fused Connection Unit with Neon

PACK: 80pcs 18



**A69-K30**  
20A Double Pole Switch with Neon

PACK: 80pcs 19



**A69-K50-2**  
45A Double Pole Switch with LED Indicator

PACK: 80pcs 20





**A69-C11**  
13A BS Socket

PACK: 80pcs 21



**A69-C29**  
13A BS Socket with Switch

PACK: 80pcs 22



**A69-C12**  
13A BS Socket with Switch & Neon

PACK: 80pcs 23



**A69-C29-3**  
13A Single Switch Socket

PACK: 80pcs 24



**A69-C36**  
16A 3 Pin Universal Socket with Switch

PACK: 80pcs 41



**A69-C37**  
16A 3 Pin Universal Switched Socket with LED Indicator Module

PACK: 80pcs 42



**A69-C45**  
16A Switched Universal Socket with Night Light

PACK: 80pcs 43



**A69-C06E29**  
2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger

PACK: 60pcs 44



**A69-C12-3**  
13A Single Switch Socket with Neon

PACK: 80pcs 25



**A69-C31-2**  
13A BS Socket with DP Switch

PACK: 80pcs 26



**A69-C32-2**  
13A BS Socket with DP Switch & LED Indicator

PACK: 80pcs 27



**A69-C29E16**  
13A BS Switched Socket with 2.1A USB Charger

PACK: 60pcs 28



**A69-C06E24**  
16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger

PACK: 60pcs 45



**A66-C06E32**  
2 Pin & 3 Pin Universal Socket with Type A+C USB Charger

PACK: 60pcs 46



**A69-E24-2**  
3.1A Double USB Charger

PACK: 60pcs 47



**A69-E31**  
20W Type A+C USB Charger

PACK: 60pcs 48



**A69-C31E16**  
13A Double Pole BS Switched Socket with 2.1A USB Charger

PACK: 60pcs 29



**A69-JAC28**  
16A 1 Gang Euro-American Socket with Switch

PACK: 80pcs 30



**A69-C28K**  
16A Switched Euro & American Socket

PACK: 80pcs 31



**A69-C28E24**  
16A Euro & American Socket with 2 Ports USB Charge

PACK: 60pcs 32



**A69-E33**  
65W Type A+C USB Charger

PACK: 60pcs 49



**A69-P37**  
45A Flex Outlet

PACK: 60pcs 50



**A69-P38**  
25A Flex Outlet

PACK: 80pcs 51



**A69-E01**  
Single Telephone Socket

PACK: 80pcs 52



**A69-C28E32**  
16A Euro & American Socket with Type A+C USB Charge

PACK: 60pcs 33



**A69-C42**  
16A Double Euro & American Socket

PACK: 80pcs 34



**A69-C18-2**  
16A 2P+E German socket

PACK: 80pcs 35




**A69-C22-2**  
16A 2P+E French socket

PACK: 80pcs 36




**A69-E02**  
Single Computer Socket

PACK: 80pcs 53



**A69-E03**  
Single TV Socket

PACK: 80pcs 54



**A69-2E01**  
Double Telephone Socket

PACK: 80pcs 55



**A69-2E02**  
Double Computer Socket (CAT.6)

PACK: 80pcs 56



**A69-C23-2**  
16A 2P European Socket

PACK: 80pcs 37



**A69-C17-2**  
15A 3 Round Pin Socket with Switch

PACK: 80pcs 38




**A69-C38**  
15A 3 Round Pin Switched Socket with LED Indicator

PACK: 80pcs 39



**A69-C06**  
16A 2 Pin & 3 Pin Universal Socket

PACK: 80pcs 40



**A69-E0102**  
Telephone & Computer Socket (CAT.6)

PACK: 80pcs 57



**A69-2E03**  
Double TV Socket

PACK: 80pcs 58



**A69-E06**  
Single Satellite Socket

PACK: 80pcs 59



**A69-E0608**  
TV & Satellite Socket

PACK: 80pcs 60





**A69-E0103**  
Telephone & TV Socket

PACK: 80pcs 61



**A69-E0203**  
Computer & TV Socket (CAT.6)

PACK: 80pcs 62



**A69-E0206**  
Computer & Satellite Socket  
Computer & Satellite Socket(CAT6)

PACK: 80pcs 63



**A69-2E07**  
2 Gang Speaker Outlet

PACK: 80pcs 64



**A69-K37**  
1W Buzzer

PACK: 80pcs 81



**A69-K31**  
3A Alarm Switch

PACK: 80pcs 82



**A69-K17**  
4A Bell Switch with  
"DO NOT DISTURB" Indicator

PACK: 80pcs 83



**A69-K18**  
4A Bell Switch with "DO NOT DISTURB"  
& "MAKE UP ROOM" Indicator

PACK: 80pcs 84



**A69-K22 A69-K24**  
Background/General Speaker  
Voice Dimmer Switch

PACK: 60pcs 65



**A69-K09**  
300W Light Dimmer Switch

PACK: 60pcs 66



**A69-K10**  
630W Light Dimmer Switch

PACK: 60pcs 67



**A69-K86**  
1000W Two Way Push Dimmer  
Switch

PACK: 60pcs 68



**A69-K21**  
4A Bell Switch with "DO NOT DISTURB"  
& "MAKE UP ROOM" & "PLEASE WAIT"  
Indicator

PACK: 80pcs 85



**A69-K15**  
16A KeyCard Switch

PACK: 60pcs 86



**A69-K43**  
16A Low Frequency Key Card  
Switch

PACK: 60pcs 87



**A69-K44**  
High Frequency Key Card  
Switch

PACK: 60pcs 88



**A69-2K100**  
Twin 100W LED Dimmer Switch

PACK: 60pcs 69



**A69-K11**  
300W Fan Dimmer Switch

PACK: 60pcs 70



**A69-K88**  
300W Two Way Push Fan  
Dimmer Switch

PACK: 60pcs 71



**A69-K93**  
100W 4 Steps Fan Dimmer Switch

PACK: 40pcs 72



**A69-K96**  
"DO NOT DISTURB" Switch

PACK: 80pcs 89



**A69-K97**  
"DO NOT DISTURB" &  
"MAKE UP ROOM" Switch

PACK: 80pcs 90



**A69-K98**  
"DO NOT DISTURB" & "MAKE UP  
ROOM" & "PLEASE WAIT" Switch

PACK: 80pcs 91



**A69-C34**  
10VA 115V- / 10A 230V-  
Shaver Socket

PACK: 16 pcs 92



**A69-K12**  
Air Control Dimmer Switch

PACK: 60pcs 73



**A69-K01BK09**  
300W Light Dimmer With  
Two Way Rocker Switch

PACK: 60pcs 74



**A69-K01BK11**  
300W Fan Dimmer With  
Two Way Rocker Switch

PACK: 60pcs 75



**A69-K25**  
45-100W Voice Activated & Light  
Sensor Switch with Time Delay

PACK: 80pcs 76



**A69-C08**  
Shaver Socket

PACK: 10pcs 93



**A69-C13**  
13A Twin BS Socket

PACK: 50pcs 94



**A69-C30**  
13A Twin BS Socket with Switch

PACK: 50pcs 95



**A69-C14**  
13A Twin BS Socket with  
Switch & Neon

PACK: 50pcs 96



**A69-K26**  
65-100W Touch Switch with  
Time Delay

PACK: 80pcs 77



**A69-K23**  
65-100W PIR Switch

PACK: 60pcs 78



**A69-K85**  
PIR Floor Light

PACK: 80pcs 79



**A69-K36**  
LED Foot Light

PACK: 60pcs 80



**A69-C30-2**  
13A Twin BS Socket with Switch

PACK: 50pcs 97



**A69-C14-2**  
13A Twin BS Socket with Switch  
& LED Indicator

PACK: 50pcs 98



**A69-C39**  
13A Twin BS Socket with DP  
Switch & LED Indicator

PACK: 50pcs 99



**A69-C40**  
13A Twin BS Socket with DP Switch  
& LED Indicator

PACK: 50pcs 100





**A69-C30E24**  
13A Twin Switched Socket with  
2 Ports USB Charger  
PACK: 40pcs 101



**A69-C14E24**  
13A Twin Switched Socket with  
2 Ports USB Charger & Neon  
PACK: 40pcs 102



**A69-C39E24**  
13A Twin DP Switched Socket with  
2 Ports USB Charger  
PACK: 40pcs 103



**A69-C40E24**  
13A Twin DP Switched Socket with  
2 Ports USB Charger & Neon  
PACK: 40pcs 104



**A69-C43**  
16A Twin Universal Switched Socket  
PACK: 50pcs 105



**A69-C43E24**  
16A Twin Universal Switched Socket  
with 2 Ports USB Charger  
PACK: 40pcs 106



**A69-C44**  
16A Twin Universal Switched Socket  
with Neon  
PACK: 50pcs 107



**A69-C44E24**  
16A Twin Universal Switched Socket  
with 2 Ports USB Charger & Neon  
PACK: 40pcs 108



**A69-C26**  
45A Cooker Unit  
PACK: 50pcs 109



**A69-K90**  
147 45A DP Switch  
PACK: 50pcs 110



**A69-K74A A69-K74B**  
10AX 147 4 Gang Switch  
PACK: 50pcs 111



**A69-K75A A69-K75B**  
10AX 147 5 Gang Switch  
PACK: 50pcs 112



**A69-P28**  
Double Blank Plate  
PACK: 100pcs 113

# A66 SERIES

- 0.4mm Brushed metal panel
- 304 stainless steel, gold aluminum optional
- Purely flat switch with LED indicator and rocker switch optional



Brushed Steel



Brushed Golden







**A66-K01A A66-K01B**  
16AX 1 Gang Switch Rocker

PACK: 80pcs 1



**A66-K02A A66-K02B**  
16AX 2 Gang Switch Rocker

PACK: 80pcs 2



**A66-K03A A66-K03B**  
16AX 3 Gang Switch Rocker

PACK: 80pcs 3



**A66-K04A A66-K04B**  
10AX 4 Gang Switch Rocker

PACK: 80pcs 4



**A66-C29-3**  
13A Single Switch Socket

PACK: 80pcs 21



**A66-C12-3**  
13A Single Switch Socket with Neon

PACK: 80pcs 22



**A66-C31-2**  
13A BS Socket with DP Switch

PACK: 80pcs 23



**A66-C32-2**  
13A BS Socket with DP Switch & LED Indicator

PACK: 80pcs 24



**E9-K16**  
16A Doorbell Switch

PACK: 80pcs 5



**E9-K16**  
16A 1 Gang Retractive Switch

PACK: 80pcs 6



**A66-K19**  
10AX 1 Gang Intermediate Switch

PACK: 80pcs 7



**A66-K20**  
10AX 2 Gang Intermediate Switch

PACK: 80pcs 8



**A66-C29E16**  
13A BS Switched Socket with 2.1A USB Charger

PACK: 60pcs 25



**A66-C31E16**  
13A Double Pole BS Switched Socket with 2.1A USB Charger

PACK: 60pcs 26



**A66-JAC28**  
16A 1 Gang Euro-American Socket with Switch

PACK: 80pcs 27



**A66-C28K**  
16A Switched Euro & American Socket

PACK: 80pcs 28



**A66-BK1A A66-BK1B**  
10AX 1 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 9



**A66-BK2A A66-BK2B**  
10AX 2 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 10



**A66-BK3A A66-BK3B**  
10AX 3 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 11



**A66-BK4A A66-BK4B**  
10AX 4 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 12



**A66-C28E24**  
16A Euro & American Socket with 2 Ports USB Charge

PACK: 60pcs 29



**A66-C28E32**  
16A Euro & American Socket with Type A+C USB Charge

PACK: 60pcs 30



**A66-C18-2**  
16A 2P+E German socket

PACK: 80pcs 31



**A66-C22-2**  
16A 2P+E French socket

PACK: 80pcs 32



**A66-K77**  
10AX 1 Gang Intermediate Full-Flat Switch with LED Indicator

PACK: 80pcs 13



**A66-P01**  
Single Blank Plate

PACK: 300pcs 14



**A66-K45 A66-K46**  
5A / 13A Fuse Switch

PACK: 80pcs 15



**A66-K30**  
20A Double Pole Switch with Neon

PACK: 80pcs 16



**A66-C23-2**  
16A 2 Pin European Socket

PACK: 80pcs 33



**A66-C17-2**  
15A 3 Round Pin Socket with Switch

PACK: 80pcs 34



**A66-C38**  
15A 3 Round Pin Switched Socket with LED Indicator

PACK: 80pcs 35



**A66-C06**  
2 Pin & 3 Pin Universal Socket

PACK: 80pcs 36



**A66-K50-2**  
45A Double Pole Switch with LED Indicator

PACK: 80pcs 17



**A66-C11**  
13A BS Socket

PACK: 80pcs 18



**A66-C29**  
13A Single Switch Socket

PACK: 80pcs 19



**A66-C12**  
13A BS Socket with Switch & Neon

PACK: 80pcs 20



**A66-C36**  
16A 3 Pin Universal Socket with Switch

PACK: 80pcs 37



**A66-C37**  
16A 3 Pin Universal Switched Socket with LED Indicator

PACK: 80pcs 38



**A66-C45**  
16A Night Light Universal Socket with 2.1A Double USB Charger

PACK: 80pcs 39



**A66-C06E29**  
2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger

PACK: 60pcs 40





**A66-C06E24**  
16A 2 Pin & 3 Pin Universal Socket  
with 3.4A Double USB Charger  
PACK: 60pcs 41



**A66-C06E32**  
2 Pin & 3 Pin Universal Socket  
with Type A+C USB Charger  
PACK: 60pcs 42



**A66-E24-2**  
3.1A Double USB Charger  
PACK: 60pcs 43



**A66-E31**  
20W Type A+C USB Charger  
PACK: 60pcs 44



**A66-K22 A66-K24**  
Background/General Speaker  
Voice Dimmer Switch  
PACK: 60pcs 61



**A66-K09**  
300W Light Dimmer Switch  
PACK: 60pcs 62



**A66-K10**  
630W Light Dimmer Switch  
PACK: 60pcs 63



**A66-K86**  
1000W Two Way Push Dimmer Switch  
PACK: 60pcs 64



**A66-E33**  
65W Type A+C USB Charger  
PACK: 60pcs 45



**A66-P37**  
45A Flex Outlet  
PACK: 60pcs 46



**A66-P38**  
25A Flex Outlet  
PACK: 80pcs 47



**A66-E01**  
Single Telephone Socket  
PACK: 80pcs 48



**A66-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 60pcs 65



**A66-K11**  
300W Fan Dimmer Switch  
PACK: 60pcs 66



**A66-K88**  
300W Two Way Push Fan  
Dimmer Switch  
PACK: 60pcs 67



**A66-K93**  
100W Step Fan Dimmer Switch  
PACK: 40pcs 68



**A66-E02**  
Computer Socket(CAT.6)  
PACK: 80pcs 49



**A66-E03**  
Single TV Socket  
PACK: 80pcs 50



**A66-2E01**  
Double Telephone Socket  
PACK: 80pcs 51



**A66-2E02**  
Double Computer Socket  
(CAT.6)  
PACK: 80pcs 52



**A66-K12**  
Air Control Dimmer Switch  
PACK: 60pcs 69



**A66-K01BK09**  
300W Light Dimmer With  
Two Way Rocker Switch  
PACK: 60pcs 70



**A66-K01BK11**  
300W Light Dimmer With  
Two Way Rocker Switch  
PACK: 60pcs 71



**A66-K25**  
65-100W Voice Activated & Light  
Sensor Switch with Time Delay  
PACK: 80pcs 72



**A66-E0102**  
Telephone & Computer Socket  
(CAT.6)  
PACK: 80pcs 53



**A66-2E03**  
Double TV Socket  
PACK: 80pcs 54



**A66-E06**  
Single Satellite Socket  
PACK: 80pcs 55



**A66-E0608**  
TV & Satellite Socket  
PACK: 80pcs 56



**A66-K26**  
65-100W Touch Switch with  
Time Delay  
PACK: 80pcs 73



**A66-K23**  
65-100W PIR Switch  
PACK: 60pcs 74



**A66-K85**  
PIR Floor Light  
PACK: 80pcs 75



**A66-K36**  
LED Foot Light  
PACK: 60pcs 76



**A66-E0103**  
Telephone & TV Socket  
PACK: 80pcs 57



**A66-E0203**  
Computer & TV Socket (CAT.6)  
PACK: 80pcs 58



**A66-E0206**  
Computer & Satellite Socket  
Computer & Satellite Socket(CAT6)  
PACK: 80pcs 59



**A66-2E07**  
2 Gang Speaker Outlet  
PACK: 80pcs 60



**A66-K37**  
1W Buzzer  
PACK: 80pcs 77



**A66-K31**  
3A Alarm Switch  
PACK: 80pcs 78



**A66-K17**  
4A Bell Switch with "DO NOT  
DISTURB" & "MAKE UP ROOM"  
Indicator  
PACK: 80pcs 79



**A66-K18**  
4A Bell Switch with "DO NOT  
DISTURB" & "MAKE UP ROOM"  
Indicator  
PACK: 80pcs 80





**A66-K21**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator  
PACK: 80pcs 81



**A66-K15**  
16A Key card Switch  
PACK: 60pcs 82



**A66-K43**  
16A Low Frequency Key Card Switch  
PACK: 60pcs 83



**A66-K44**  
16A High Frequency Key Card Switch  
PACK: 60pcs 84



**A66-C44**  
16A Twin Universal Switched Socket with Neon  
PACK: 50pcs 101



**A66-C44E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 102



**A66-C26**  
45A Cooker Unit  
PACK: 50pcs 103



**A66-K90**  
147 45A DP Switch  
PACK: 50pcs 104



**A66-K96**  
"DO NOT DISTURB" Switch  
PACK: 80pcs 85



**A66-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch  
PACK: 80pcs 86



**A66-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch  
PACK: 80pcs 87



**A66-C34**  
10VA 115V- / 10A 230V- Shaver Socket  
PACK: 16 pcs 88



**A66-P28**  
Double Blank Plate  
PACK: 160pcs 105



**A66-K74A A66-K74B**  
10AX 147 4 Gang Switch  
PACK: 50pcs 106



**A66-K75A A66-K75B**  
10AX 147 5 Gang Switch  
PACK: 50pcs 107



**A66-C08**  
Shaver Socket  
PACK: 10pcs 89



**A66-C13**  
13A Twin BS Socket  
PACK: 50pcs 90



**A66-C30-2**  
13A Twin BS Socket with Switch  
PACK: 50pcs 91



**A66-C14-2**  
13A Twin BS Socket with Switch & LED Indicator  
PACK: 50pcs 92



**A66-C39**  
13A Twin BS Socket with DP Switch  
PACK: 50pcs 93



**A66-C40**  
13A Twin BS Socket with DP Switch & LED Indicator  
PACK: 50pcs 94



**A66-C30E24**  
13A Twin Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 95



**A66-C14E24**  
13A Twin Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 96



**A66-C39E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 97



**A66-C40E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 98



**A66-C43**  
16A Twin Universal Switched Socket  
PACK: 50pcs 99



**A66-C43E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 100



# A68 SERIES

- Modern style design
- Purely flat switch with LED indicator
- Three color optional



**A68-BK1A A68-BK1B**  
10AX 1 Gang Full-Flat Switch  
with LED Indicator  
PACK: 80pcs 1



**A68-BK2A A68-BK2B**  
10AX 2 Gang Full-Flat Switch  
with LED Indicator  
PACK: 80pcs 2



**A68-BK3A A68-BK3B**  
10AX 3 Gang Full-Flat Switch  
with LED Indicator  
PACK: 80pcs 3



**A68-BK4A A68-BK4B**  
10AX 4 Gang Full-Flat Switch  
with LED Indicator  
PACK: 80pcs 4



**A68-K77**  
10AX 1 Gang Intermediate Full-Flat  
Switch with LED Indicator  
PACK: 80pcs 5



**A68-P01**  
Single Blank  
PACK: 200pcs 6



**A68-K45 A68-K46**  
5A/13A Switched Fused  
Connection Unit with Neon  
PACK: 80pcs 7



**A68-K30**  
20A Double Pole Switch with  
Neon  
PACK: 80pcs 8



**A68-K50-2**  
45A Double Pole Switch with  
LED Indicator  
PACK: 80pcs 9



**A68-C11**  
13A BS Socket  
PACK: 80pcs 10



**A68-C29-3**  
13A Single Switch Socket  
PACK: 80pcs 11



**A68-C12-3**  
13A Single Switch Socket  
with Neon  
PACK: 80pcs 12



**A68-C31**  
13A Single Socket with DP  
Switch  
PACK: 80pcs 13



**A68-C32**  
13A Single Socket with DP  
Switch & Neon  
PACK: 80pcs 14



**A68-C29E16**  
13A BS Switched Socket  
with 2.1A USB Charger  
PACK: 60pcs 15



**A68-C31E16**  
13A Double Pole BS Switched  
Socket with 2.1A USB Charger  
PACK: 60pcs 16



**A68-JAC28**  
16A 1 Gang Euro-American  
Socket with Switch  
PACK: 80pcs 17



**A68-C28K**  
16A Switched Euro & American  
Socket  
PACK: 80pcs 18



**A68-C28E24**  
16A Euro & American Socket  
with 2 Ports USB Charge  
PACK: 60pcs 19



**A68-C28E32**  
16A Euro & American Socket  
with Type A+C USB Charge  
PACK: 60pcs 20





**A68-C18-2**  
16A 2P + E German Socket

PACK: 80pcs 21



**A68-C22-2**  
16A 2P+E French Socket

PACK: 80pcs 22



**A68-C23-2**  
16A 2P European Socket

PACK: 80pcs 23



**A68-C17-2**  
15A 3 Round Pin Socket with Switch  
PACK: 80pcs 24



**A68-2E01**  
Double Telephone Socket  
PACK: 80pcs 41



**A68-2E02**  
Double Computer Socket (CAT.6)  
PACK: 80pcs 42



**A68-E0102**  
Telephone & Computer Socket (CAT.6)  
PACK: 80pcs 43



**A68-2E03**  
Double TV Socket  
PACK: 80pcs 44



**A68-C38**  
15A 3 Round Pin Switched Socket with LED Indicator  
PACK: 80pcs 25



**A68-C06**  
16A 2 Pin & 3 Pin Universal Socket  
PACK: 80pcs 26



**A68-C36**  
16A 3 Pin Universal Socket with Switch  
PACK: 80pcs 27



**A68-C37**  
16A 3 Pin Universal Switched Socket with LED Indicator  
PACK: 80pcs 28



**A68-E06**  
Single Satellite Socket  
PACK: 80pcs 45



**A68-E0608**  
TV & Satellite Socket  
PACK: 80pcs 46



**A68-E0103**  
Telephone & TV Socket  
PACK: 80pcs 47



**A68-E0203**  
Computer & TV Socket (CAT.6)  
PACK: 80pcs 48



**A68-C45**  
16A Switched Universal Socket with Night Light  
PACK: 80pcs 29



**A68-C06E29**  
2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger  
PACK: 60pcs 30



**A68-C06E24**  
2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger  
PACK: 60pcs 31



**A68-C06E32**  
2 Pin & 3 Pin Universal Socket with Type A+C USB Charger  
PACK: 60pcs 32



**A68-E0206**  
Computer & Satellite Socket (CAT6)  
PACK: 80pcs 49



**A68-2E07**  
2 Gang Speaker Outlet  
PACK: 80pcs 50



**A68-K22 A68-K24**  
Background/General Speaker Voice Dimmer Switch  
PACK: 60pcs 51



**A68-K09**  
300W Light Dimmer Switch  
PACK: 60pcs 52



**A68-E24-2**  
3.1A Double USB Charger  
PACK: 60pcs 33



**A68-E31**  
20W Type A+C USB Charger  
PACK: 60pcs 34



**A68-E33**  
65W Type A+C USB Charger  
PACK: 60pcs 35



**A68-P37**  
45A Flex Outlet  
PACK: 60pcs 36



**A68-K10**  
630W Light Dimmer Switch  
PACK: 60pcs 53



**A68-K86**  
1000W Two Way Push Dimmer Switch  
PACK: 60pcs 54



**A68-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 60pcs 55



**A68-K11**  
300W Fan Dimmer Switch  
PACK: 60pcs 56



**A68-P38**  
25A Flex Outlet  
PACK: 80pcs 37



**A68-E01**  
Single Telephone Socket  
PACK: 80pcs 38



**A68-E02**  
Computer Socket (CAT.6)  
PACK: 80pcs 39



**A68-E03**  
Single TV Socket  
PACK: 80pcs 40



**A68-K88**  
300W Two Way Push Fan Dimmer Switch  
PACK: 60pcs 57



**A68-K93**  
100W Step Fan Dimmer Switch  
PACK: 40pcs 58



**A68-K12**  
Air Control Dimmer Switch  
PACK: 60pcs 59



**A68-K01BK09**  
300W Light Dimmer With Two Way Rocker Switch  
PACK: 60pcs 60





**A68-K01BK11**  
300W Fan Dimmer With Two Way Rocker Switch  
PACK: 60pcs 61



**A68-K25**  
45-100W Voice Activated & Light Sensor Switch with Time Delay  
PACK: 80pcs 62



**A68-K26**  
45-100W Touch Switch with Time Delay  
PACK: 80pcs 63



**A68-K23**  
65-100W PIR Switch  
PACK: 60pcs 64



**A68-C30-2**  
13A Twin BS Socket with Switch  
PACK: 50pcs 81



**A68-C14-2**  
13A Twin BS Socket with Switch & LED Indicator  
PACK: 50pcs 82



**A68-C39**  
13A Twin BS Socket with DP Switch  
PACK: 50pcs 83



**A68-C40**  
13A Twin BS Socket with DP Switch & LED Indicator  
PACK: 50pcs 84



**A68-K85**  
PIR Foot Light  
PACK: 80pcs 65



**A68-K36**  
15mA LED Foot Light  
PACK: 60pcs 66



**A68-K37**  
1W Buzzer  
PACK: 80pcs 67



**A68-K31**  
3A Alarm Switch  
PACK: 80pcs 68



**A68-C30E24**  
13A Twin Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 85



**A68-C14E24**  
13A Twin Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 86



**A68-C39E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 87



**A68-C40E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 88



**A68-K17**  
4A Bell Switch with "DO NOT DISTURB" Indicator  
PACK: 80pcs 69



**A68-K18**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator  
PACK: 80pcs 70



**A68-K21**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator  
PACK: 80pcs 71



**A68-K15**  
16A Key card switch  
PACK: 60pcs 72



**A68-C43**  
16A Twin Universal Switched Socket  
PACK: 50pcs 89



**A68-C43E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 90



**A68-C44**  
16A Twin Universal Switched Socket with Neon  
PACK: 50pcs 91



**A68-C44E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 92



**A68-K43**  
Low Frequency Key Card Switch  
PACK: 60pcs 73



**A68-K44**  
High Frequency Key Card Switch  
PACK: 60pcs 74



**A68-K96**  
"DO NOT DISTURB" Switch  
PACK: 80pcs 75



**A68-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch  
PACK: 80pcs 76



**A68-C26**  
45A Cooker Unit  
PACK: 50pcs 93



**A68-K90**  
147 45A DP Switch  
PACK: 50pcs 94



**A68-P28**  
Double Blank Plate  
PACK: 160pcs 95



**A68-K74A A68-K74B**  
10AX 147 4 Gang Switch  
PACK: 50pcs 96



**A68-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch  
PACK: 80pcs 77



**A68-C34**  
10VA 115V~ / 10A 230V~ Shaver Socket  
PACK: 16 pcs 78



**A68-C08**  
Shaver Socket  
PACK: 10pcs 79



**A68-C13**  
13A Twin BS Socket  
PACK: 50pcs 80



**A68-K75A A68-K75B**  
10AX 147 5 Gang Switch  
PACK: 50pcs 97

# A38 SERIES

- Mirror decorative strip LED light switch
- Reversing touch control technology, high power LED loading
- Large aperture connecting terminal



White



Golden



**A38-K01A A38-K01B**  
10AX 1 Gang Switch Rocker

PACK: 80pcs 1



**A38-K02A A38-K02B**  
10AX 2 Gang Switch Rocker

PACK: 80pcs 2



**A38-K03A A38-K03B**  
10AX 3 Gang Switch Rocker

PACK: 80pcs 3



**A38-K04A A38-K04B**  
10AX 4 Gang Switch Rocker

PACK: 80pcs 4



**A38-K16**  
10A Doorbell Switch

PACK: 80pcs 5




**A38-K19**  
10AX 1 Gang Intermediate Switch

PACK: 80pcs 6



**A38-K20**  
10AX 2 Gang Intermediate Switch

PACK: 80pcs 7



**A38-P01**  
Single Blank

PACK: 200pcs 8



**A38-K45 A38-K46**  
5A / 13A Switched Fused  
Connection Unit with Neon

PACK: 80pcs 9




**A38-K30**  
20A Double Pole Switch  
with Neon

PACK: 80pcs 10



**A38-K50-2**  
45A Double Pole Switch with  
LED Indicator

PACK: 80pcs 11



**A38-C11-2**  
13A BS Socket

PACK: 80pcs 12



**A38-C29-3**  
13A Single Switch Socket

PACK: 80pcs 13



**A38-C12-3**  
13A Single Switch Socket  
with Neon

PACK: 80pcs 14




**A38-C31-2**  
13A BS Socket with DP Switch

PACK: 80pcs 15




**A38-C32-2**  
13A BS Socket with DP Switch  
& LED Indicator

PACK: 80pcs 16




**A38-C29E16**  
13A BS Switched Socket with  
2.1A USB Charger

PACK: 60pcs 17




**A38-C31E16**  
13A Double Pole BS Switched  
Socket with 2.1A USB Charger

PACK: 60pcs 18



**A38-JAC28**  
16A 1 Gang Euro-American  
Socket with Switch

PACK: 80pcs 19



**A38-C28K**  
16A Switched Euro & American  
Socket

PACK: 80pcs 20






**A38-C28E24**  
16A Euro & American Socket  
with 2 Ports USB Charge  
PACK: 60pcs 21



**A38-C28E32**  
16A Euro & American Socket  
with Type A+C USB Charge  
PACK: 60pcs 22



**A38-C42**  
16A Twin Euro & American Socket  
PACK: 80pcs 23



**A38-C18-2**  
16A 2P + E German Socket  
PACK: 80pcs 24



**A38-E01**  
Single Telephone Socket  
PACK: 80pcs 41



**A38-E02**  
Single Computer Socket  
PACK: 80pcs 42




**A38-E03**  
Single TV Socket  
PACK: 80pcs 43



**A38-2E01**  
Double Telephone Socket  
PACK: 80pcs 44



**A38-C22-2**  
16A 2P+E French Socket  
PACK: 80pcs 25



**A38-C23-2**  
16A 2P European Socket  
PACK: 80pcs 26



**A38-C17-2**  
15A 3 Round Pin Socket  
with Switch  
PACK: 80pcs 27



**A38-C38**  
15A 3 Round Pin Switched  
Socket with LED Indicator  
PACK: 80pcs 28



**A38-2E02**  
Double Computer Socket  
(CAT.6)  
PACK: 80pcs 45



**A38-E0102**  
Telephone & Computer Socket  
(CAT.6)  
PACK: 80pcs 46



**A38-2E03**  
Double TV Socket  
PACK: 80pcs 47



**A38-E06**  
Single Satellite Socket  
PACK: 80pcs 48



**A38-C06**  
16A 2 Pin & 3 Pin Universal  
Socket  
PACK: 80pcs 29



**A38-C36**  
16A 3 Pin Universal Socket  
with Switch  
PACK: 80pcs 30



**A38-C37**  
16A 3 Pin Universal Switched  
Socket with LED Indicator Module  
PACK: 80pcs 31



**A38-C45**  
16A Switched Universal Socket  
with Night Light  
PACK: 80pcs 32



**A38-E0608**  
TV & Satellite Socket  
PACK: 80pcs 49



**A38-E0103**  
Telephone & TV Socket  
PACK: 80pcs 50



**A38-E0203**  
Computer & TV Socket  
(CAT.6)  
PACK: 80pcs 51



**A38-E0206**  
Computer & Satellite Socket  
(CAT.6)  
PACK: 80pcs 52



**A38-C06E29**  
2 Pin & 3 Pin Universal Socket  
with 2.1A Double USB Charger  
PACK: 60pcs 33



**A38-C06E24**  
16A 2 Pin & 3 Pin Universal Socket  
with 3.4A Double USB Charger  
PACK: 60pcs 34



**A38-C06E32**  
2 Pin & 3 Pin Universal Socket  
with Type A+C USB Charger  
PACK: 60pcs 35



**A38-E24-2**  
3.1A Double USB Charger  
PACK: 60pcs 36



**A38-2E07**  
2 Gang Speaker Outlet  
PACK: 80pcs 53



**A38-K09**  
300W Light Dimmer Switch  
PACK: 60pcs 54



**A38-K86**  
1000W Two Way Push Dimmer  
Switch  
PACK: 60pcs 55



**A38-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 60pcs 56



**A38-E31**  
20W Type A+C USB Charger  
PACK: 60pcs 37



**A38-E33**  
65W Type A+C USB Charger  
PACK: 60pcs 38



**A38-P37**  
45A Flex Outlet  
PACK: 60pcs 39



**A38-P38**  
25A Flex Outlet  
PACK: 80pcs 40



**A38-K11**  
300W Fan Dimmer Switch  
PACK: 60pcs 57



**A38-K88**  
300W Two Way Push Fan  
Dimmer Switch  
PACK: 60pcs 58



**A38-K93**  
100W Step Fan Dimmer Switch  
PACK: 40pcs 59



**A38-K12**  
Air Control Dimmer Switch  
PACK: 60pcs 60



**A38-K01BK09**  
300W Light Dimmer With Two Way Rocker Switch  
PACK: 60pcs 61



**A38-K01BK11**  
300W Fan Dimmer With Two Way Rocker Switch  
PACK: 60pcs 62



**A38-K25**  
65-100W Voice Activated & Light Sensor Switch with Time Delay  
PACK: 80pcs 63



**A38-K26**  
65-100W Touch Switch with Time Delay  
PACK: 80pcs 64



**A38-C13**  
13A Twin BS Socket  
PACK: 50pcs 81



**A38-C30**  
13A Twin Switched Socket  
PACK: 50pcs 82



**A38-C14**  
13A Twin Socket with switch & LED Indicator  
PACK: 50pcs 83



**A38-C39**  
13A DP Twin Switched Socket  
PACK: 50pcs 84



**A38-K23**  
65-100W PIR Switch  
PACK: 60pcs 65



**A38-K85**  
PIR Foot Light  
PACK: 80pcs 66



**A38-K36**  
LED Foot Light  
PACK: 80pcs 67



**A38-K37**  
1W Buzzer  
PACK: 80pcs 68



**A38-C40**  
13A DP Twin Socket with switch & LED Indicator  
PACK: 50pcs 85



**A38-C30E24**  
13A Twin Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 86



**A38-C14E24**  
13A Twin Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 87



**A38-C39E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 88



**A38-K31**  
3A Alarm Switch  
PACK: 80pcs 69



**A38-K17**  
2A Bell Switch with "DO NOT DISTURB" Indicator  
PACK: 80pcs 70



**A38-K18**  
2A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator  
PACK: 80pcs 71



**A38-K21**  
2A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator  
PACK: 80pcs 72



**A38-C40E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 89



**A38-C43**  
16A Twin Universal Switched Socket  
PACK: 50pcs 90



**A38-C43E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 91



**A38-C44**  
16A Twin Universal Switched Socket with Neon  
PACK: 50pcs 92



**A38-K15**  
16A KeyCard Switch  
PACK: 60pcs 73



**A38-K43**  
16A Low Frequency KeyCard Switch  
PACK: 60pcs 74



**A38-K44**  
16A High Frequency KeyCard Switch  
PACK: 60pcs 75



**A38-K96**  
"DO NOT DISTURB" Switch  
PACK: 80pcs 76




**A38-C44E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 93



**A38-C26**  
45A Cooker Unit  
PACK: 50pcs 94



**A38-K90**  
147 45A DP Switch  
PACK: 50pcs 95



**A38-P28**  
Double Blank  
PACK: 160pcs 96




**A38-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch  
PACK: 80pcs 77



**A38-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch  
PACK: 80pcs 78



**A38-C34**  
3X3 Shaver Socket  
PACK: 16pcs 79



**A38-C08**  
Shaver Socket  
PACK: 10pcs 80



# D3 SERIES

- Simple Large Panel Design
- High Current Load Design For Larger LED Loading
- Large Size Sliding Terminal For Easier Wiring



White



Matt Black



**D3-K01A D3-K01B**  
10AX 1 Gang Switch

PACK: 100pcs 1



**D3-K02A D3-K02B**  
10AX 2 Gang Switch

PACK: 100pcs 2



**D3-K03A D3-K03B**  
10AX 3 Gang Switch

PACK: 100pcs 3



**D3-K04A D3-K04B**  
10AX 4 Gang Switch

PACK: 100pcs 4



**V8-K16**  
10A Doorbell Switch

PACK: 100pcs 5



**V8-K16**  
10A 1 Gang Retractive Switch

PACK: 100pcs 6



**D3-K19**  
10AX 1 Gang Intermediate Switch

PACK: 100pcs 7



**D3-K20**  
10AX 2 Gang Intermediate Switch

PACK: 100pcs 8



**D3-P01**  
Single Blank Plate

PACK: 200pcs 9



**D3-K45 D3-K46**  
5A/13A Switched Fused Connection Unit with Neon

PACK: 100pcs 10



**D3-K30**  
20A Double Pole Switch with Neon

PACK: 100pcs 11



**D3-K50**  
45A Double Pole Switch with LED Indicator

PACK: 100pcs 12



**D3-C11**  
13A BS Socket

PACK: 100pcs 13



**D3-C29**  
13A BS Socket with Switch

PACK: 100pcs 14



**D3-C12**  
13A Single Switched Socket with Neon

PACK: 100pcs 15



**D3-C31**  
13A BS Socket with DP Switch

PACK: 100pcs 16



**D3-C32**  
13A Single Socket with DP Switch & Neon

PACK: 100pcs 17



**D3-C29E16**  
13A BS Switched Socket with 2.1A USB Charger

PACK: 80pcs 18



**D3-C31E16**  
13A Double Pole BS Switched Socket with 2.1A USB Charger

PACK: 80pcs 19



**D3-JAC28**  
16A 1 Gang Euro-American Socket with Switch

PACK: 100pcs 20




**D3-C28K**  
16A Switched Euro & American Socket  
PACK: 100pcs 21



**D3-C28E24**  
16A Euro & American Socket with 2 Ports USB Charge  
PACK: 80pcs 22



**D3-C28E32**  
16A Euro & American Socket with Type A+C USB Charge  
PACK: 80pcs 23



**D3-C42**  
16A Twin Euro & American Socket  
PACK: 100pcs 24



**D3-P38**  
25A Flex Outlet  
PACK: 100pcs 41



**D3-E01**  
Single Telephone Socket  
PACK: 100pcs 42



**D3-E02**  
Single Computer Socket  
PACK: 100pcs 43



**D3-E03**  
Single TV Socket  
PACK: 100pcs 44




**D3-C18**  
16A 2P + E German Socket  
PACK: 100pcs 25



**D3-C22**  
16A 2P+E French Socket  
PACK: 100pcs 26



**D3-C23**  
16A 2P European Socket  
PACK: 100pcs 27



**D3-C17**  
15A 3 Round Pin Socket with Switch  
PACK: 100pcs 28



**D3-2E01**  
Double Telephone Socket  
PACK: 100pcs 45



**D3-2E02**  
Double Computer Socket (CAT.6)  
PACK: 100pcs 46



**D3-E0102**  
Telephone & Computer Socket (CAT.6)  
PACK: 100pcs 47



**D3-2E03**  
Double TV Socket  
PACK: 100pcs 48



**D3-C38**  
15A 3 Round Pin Switched Socket with LED Indicator  
PACK: 100pcs 29



**D3-C06**  
16A 2 Pin & 3 Pin Universal Socket  
PACK: 100pcs 30



**D3-C36**  
16A 3 Pin Universal Socket with Switch  
PACK: 100pcs 31



**D3-C37**  
16A 3 Pin Universal Switched Socket with LED Indicator  
PACK: 100pcs 32



**D3-E06**  
Single Satellite Socket  
PACK: 100pcs 49



**D3-E0608**  
TV & Satellite Socket  
PACK: 100pcs 50



**D3-E0103**  
Telephone & TV Socket  
PACK: 100pcs 51



**D3-E0203**  
Computer & TV Socket (CAT.6)  
PACK: 100pcs 52



**D3-C45**  
16A Switched Universal Socket with Night Light  
PACK: 80pcs 33



**D3-C06E29**  
2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger  
PACK: 80pcs 34



**D3-C06E24**  
16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger  
PACK: 80pcs 35



**D3-C06E32**  
2 Pin & 3 Pin Universal Socket with Type A+C USB Charger  
PACK: 80pcs 36



**D3-E0206**  
Computer & Satellite Socket (CAT6)  
PACK: 100pcs 53



**D3-2E07**  
2 Gang Speaker Outlet  
PACK: 100pcs 54



**D3-K22 D3-K24**  
Background/General Speaker Voice Dimmer Switch  
PACK: 80pcs 55



**D3-K09**  
300W Light Dimmer Switch  
PACK: 80pcs 56



**D3-E24-2**  
3.1A Double USB Charger  
PACK: 80pcs 37



**D3-E31**  
20W Type A+C USB Charger  
PACK: 80pcs 38



**D3-E33**  
65W Type A+C USB Charger  
PACK: 80pcs 39



**D3-P37**  
45A Flex Outlet  
PACK: 80pcs 40



**D3-K10**  
630W Light Dimmer Switch  
PACK: 80pcs 57



**D3-K86**  
1000W Two Way Push Dimmer Switch  
PACK: 60pcs 58



**D3-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 80pcs 59



**D3-K11**  
300W Fan Dimmer Switch  
PACK: 80pcs 60





**D3-K88**  
300W Two Way Push Fan Dimmer Switch  
PACK: 60pcs 61



**D3-K93**  
100W Step Fan Dimmer Switch  
PACK: 60pcs 62



**D3-K12**  
Air Control Dimmer Switch  
PACK: 80pcs 63



**D3-K01BK09**  
300W Light Dimmer With Two Way Rocker Switch  
PACK: 80pcs 64




**D3-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch  
PACK: 100pcs 81



**D3-C34**  
10VA 115V- / 10A 230V- Shaver Socket  
PACK: 16pcs 82



**D3-C08**  
3X6 Shaver Socket  
PACK: 10pcs 83



**D3-C13**  
13A Twin BS Socket  
PACK: 70pcs 84



**D3-K01BK11**  
300W Fan Dimmer With Two Way Rocker Switch  
PACK: 80pcs 65



**D3-K25**  
Acousto-optic Controlled Switch with Time Delay  
PACK: 100pcs 66



**D3-K26**  
Touch Switch with Time Delay  
PACK: 100pcs 67



**D3-K23**  
PIR Switch  
PACK: 80pcs 68



**D3-C30**  
13A Twin BS Socket with Switch  
PACK: 70pcs 85



**D3-C14**  
13A Twin BS Socket with Switch & LED Indicator  
PACK: 70pcs 86



**D3-C39**  
13A Twin BS Socket with DP Switch  
PACK: 70pcs 87



**D3-C40**  
13A Twin BS Socket with DP Switch & LED Indicator  
PACK: 70pcs 88



**D3-K85**  
PIR Foot Light  
PACK: 100pcs 69



**D3-K36**  
15mA LED Foot Light  
PACK: 100pcs 70



**D3-K37**  
1W Buzzer  
PACK: 100pcs 71



**D3-K31**  
3A Alarm Switch  
PACK: 100pcs 72



**D3-C30E24**  
13A Twin Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 89



**D3-C14E24**  
13A Twin Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 90



**D3-C39E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 91



**D3-C40E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 92



**D3-K17**  
4A Bell Switch with "DO NOT DISTURB" Indicator  
PACK: 100pcs 73



**D3-K18**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator  
PACK: 100pcs 74



**D3-K21**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator  
PACK: 100pcs 75



**D3-K15**  
16A KeyCard Switch  
PACK: 80pcs 76



**D3-C43**  
16A Twin Universal Switched Socket  
PACK: 60pcs 93



**D3-C43E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 94



**D3-C44**  
16A Twin Universal Switched Socket with Neon  
PACK: 60pcs 95



**D3-C44E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 96



**D3-K43**  
16A Low Frequency KeyCard Switch  
PACK: 80pcs 77



**D3-K44**  
16A High Frequency KeyCard Switch  
PACK: 80pcs 78



**D3-K96**  
"DO NOT DISTURB" Switch  
PACK: 100pcs 79



**D3-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch  
PACK: 100pcs 80



**D3-C26**  
45A Cooker Unit  
PACK: 50pcs 97



**D3-K90**  
147 45A DP Switch  
PACK: 60pcs 98



**D3-P28**  
Double Blank Plate  
PACK: 140pcs 99

# A63 SERIES

- Frameless design with big cambered surface
- Golden White optional
- Reversing touch control technology, high power LED loading.
- Large aperture connecting terminal



**A63-K01A A63-K01B**  
10AX 1 Gang Switch Rocker  
PACK: 100pcs      1



**A63-K02A A63-K02B**  
10AX 2 Gang Switch Rocker  
PACK: 100pcs      2



**A63-K03A A63-K03B**  
10AX 3 Gang Switch Rocker  
PACK: 100pcs      3



**A63-K04A A63-K04B**  
10AX 4 Gang Switch Rocker  
PACK: 100pcs      24



**A63-K16**  
10A Doorbell Switch  
PACK: 100pcs      5



**A63-K16**  
10A 1 Gang Retractive Switch  
PACK: 100pcs      6



**A63-K19**  
10AX 1 Gang Intermediate Switch  
PACK: 100pcs      7



**A63-K20**  
10AX 2 Gang Intermediate Switch  
PACK: 100pcs      8



**A63-K45**  
5A Switched Fused Connection Unit with Neon  
PACK: 100pcs      9



**A63-K30**  
20A Double Pole Switch with Neon  
PACK: 100pcs      10



**A63-K50-2**  
45A Double Pole Switch with LED Indicator  
PACK: 100pcs      11



**A63-C11-2**  
13A BS Socket  
PACK: 100pcs      12



**A63-C29-3**  
13A Single Switch Socket  
PACK: 100pcs      13



**A63-C12-3**  
13A Single Switch Socket with Neon  
PACK: 100pcs      14



**A63-C31-2**  
13A BS Socket with DP Switch  
PACK: 100pcs      15



**A63-C32-2**  
13A BS Socket with DP Switch & LED Indicator  
PACK: 100pcs      16



**A63-C29E16**  
13A BS Switched Socket with 2.1A USB Charger  
PACK: 80pcs      17



**A63-C31E16**  
13A Double Pole BS Switched Socket with 2.1A USB Charger  
PACK: 80pcs      18



**A63-JAC28**  
16A 1 Gang Euro-American Socket with Switch  
PACK: 100pcs      19



**A63-C28K**  
16A Switched Euro & American Socket  
PACK: 100pcs      20





**A63-C28E24**  
16A Euro & American Socket  
with 2 Ports USB Charge  
PACK: 80pcs 21



**A63-C28E32**  
16A Euro & American Socket  
with Type A+C USB Charge  
PACK: 80pcs 22



**A63-C42**  
16A Twin Euro & American  
Socket  
PACK: 100pcs 23



**A63-C18**  
16A 2P + E German Socket  
PACK: 100pcs 24



**A63-E01**  
Single Telephone Socket  
PACK: 100pcs 41



**A63-E02**  
Single Computer Socket  
PACK: 100pcs 42



**A63-E03**  
Single TV Socket  
PACK: 100pcs 43



**A63-2E01**  
Double Telephone Socket  
PACK: 100pcs 44



**A63-C22**  
16A 2P+E French Socket  
PACK: 100pcs 25



**A63-C23**  
16A 2P European Socket  
PACK: 100pcs 26



**A63-C17-2**  
15A 3 Round Pin Socket  
with Switch  
PACK: 100pcs 27



**A63-C38**  
15A 3 Round Pin Switched  
Socket with LED Indicator  
PACK: 100pcs 28



**A63-2E02**  
Double Computer Socket  
(CAT.6)  
PACK: 100pcs 45



**A63-E0102**  
Telephone & Computer  
Socket (CAT.6)  
PACK: 100pcs 46



**A63-2E03**  
Double TV Socket  
PACK: 100pcs 47



**A63-E06**  
Single Satellite Socket  
PACK: 100pcs 48



**A63-C06**  
16A 2 Pin & 3 Pin Universal Socket  
PACK: 100pcs 29



**A63-C36**  
16A 3 Pin Universal Socket  
with Switch  
PACK: 100pcs 30



**A63-C37**  
16A 3 Pin Universal Switched  
Socket with LED Indicator Module  
PACK: 100pcs 31



**A63-C45**  
16A Switched Universal Socket  
with Night Light  
PACK: 100pcs 32



**A63-E0608**  
TV & Satellite Socket  
PACK: 100pcs 49



**A63-E0103**  
Telephone & TV Socket  
PACK: 100pcs 50



**A63-E0203**  
Computer & TV Socket  
PACK: 100pcs 51



**A63-E0206**  
Computer & Satellite Socket  
(CAT6)  
PACK: 100pcs 52



**A63-JAC06-L**  
16A 2 Pin & 3 Pin Universal  
Switched Socket with Neon  
PACK: 100pcs 33



**A63-C06E24**  
16A 2 Pin & 3 Pin Universal Socket  
with 3.4A Double USB Charger  
PACK: 80pcs 34



**A63-C06E32**  
2 Pin & 3 Pin Universal Socket  
with Type A+C USB Charger  
PACK: 80pcs 35



**A63-E24-2**  
3.1A Double USB Charger  
PACK: 80pcs 36



**A63-2E07**  
2 Gang Speaker Outlet  
PACK: 100pcs 53



**A63-K22 A63-K24**  
Background/General Speaker  
Voice Dimmer Switch  
PACK: 80pcs 54



**A63-K09**  
300W Light Dimmer Switch  
PACK: 80pcs 55



**A63-K10**  
630W Light Dimmer Switch  
PACK: 80pcs 56



**A63-E31**  
20W Type A+C USB Charger  
PACK: 80pcs 37



**A63-E33**  
65W Type A+C USB Charger  
PACK: 80pcs 38



**A63-P37**  
45A Flex Outlet  
PACK: 80pcs 39



**A63-P38**  
25A Flex Outlet  
PACK: 100pcs 40



**A63-K86**  
1000W Two Way Push Dimmer  
Switch  
PACK: 60pcs 57



**A63-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 80pcs 58



**A63-K11**  
300W Fan Dimmer Switch  
PACK: 80pcs 59



**A63-K88**  
300W Two Way Push Fan  
Dimmer Switch  
PACK: 60pcs 60



**A63-K93**  
100W Step Fan Dimmer Switch  
PACK: 60pcs 61



**A63-K12**  
Air Control Dimmer Switch  
PACK: 80pcs 62



**A63-K01BK09**  
300W Light Dimmer With Two Way Rocker Switch  
PACK: 80pcs 63



**A63-K01BK11**  
300W Fan Dimmer With Two Way Rocker Switch  
PACK: 80pcs 64



**A63-C34**  
10VA 115V- / 10A 230V- Shaver Socket  
PACK: 16pcs 81



**A63-C08**  
Shaver Socket  
PACK: 10pcs 82



**A63-C13**  
13A Twin BS Socket  
PACK: 70pcs 83



**A63-C30-2**  
13A Twin BS Socket with Switch  
PACK: 70pcs 84



**A63-K25**  
45-100W Voice Activated & Light Sensor Switch with Time Delay  
PACK: 100pcs 65



**A63-K26**  
45-100W Touch Switch with Time Delay  
PACK: 100pcs 66



**A63-K23**  
65-100W PIR Switch  
PACK: 80pcs 67



**A63-K85**  
PIR Foot Light  
PACK: 80pcs 68



**A63-C14-2**  
13A Twin BS Socket with Switch & LED Indicator  
PACK: 70pcs 85



**A63-C39**  
13A Twin BS Socket with DP Switch  
PACK: 70pcs 86



**A63-C40**  
13A Twin BS Socket with DP Switch & LED Indicator  
PACK: 70pcs 87



**A63-C30E24**  
13A Twin Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 88



**A63-K36**  
15mA LED Foot Light  
PACK: 100pcs 69



**A63-K37**  
1W Buzzer  
PACK: 100pcs 70



**A63-K31**  
3A Alarm Switch  
PACK: 100pcs 71



**A63-K17**  
4A Bell Switch with "DO NOT DISTURB" Indicator  
PACK: 100pcs 72



**A63-C14E24**  
13A Twin Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 89



**A63-C39E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 90



**A63-C40E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 91



**A63-C43**  
16A Twin Universal Switched Socket  
PACK: 60pcs 92



**A63-K18**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator  
PACK: 100pcs 73



**A63-K21**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator  
PACK: 100pcs 74



**A63-K15**  
16A KeyCard Switch  
PACK: 80pcs 75



**A63-K43**  
16A Low Frequency KeyCard Switch  
PACK: 80pcs 76



**A63-C43E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 93



**A63-C44**  
16A Twin Universal Switched Socket with Neon  
PACK: 60pcs 94



**A63-C44E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 95



**A63-C26**  
45A Cooker Unit  
PACK: 60pcs 96



**A63-K44**  
16A High Frequency KeyCard Switch  
PACK: 80pcs 77



**A63-K96**  
"DO NOT DISTURB" Switch  
PACK: 100pcs 78



**A63-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch  
PACK: 100pcs 79



**A63-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch  
PACK: 100pcs 80



**A63-K90**  
147 45A DP Switch  
PACK: 60pcs 97



**A63-P28**  
Double Blank Plate  
PACK: 140pcs 98



# E3 SERIES

- Modern minimalist design
- 16AX High-current rocker switch
- Purely flat switch with LED indicator



**E-K01A E-K01B**  
16AX 1 Gang Switch Rocker

PACK: 80pcs 1



**E-K02A E-K02B**  
16AX 2 Gang Switch Rocker

PACK: 80pcs 2



**E-K03A E-K03B**  
16AX 3 Gang Switch Rocker

PACK: 80pcs 3




**E-K04A E-K04B**  
10AX 4 Gang Switch Rocker

PACK: 80pcs 4



**E9-K16**  
16A Doorbell Switch

PACK: 80pcs 5




**E9-K16**  
16A 1 Gang Retractive Switch

PACK: 80pcs 6




**E-K19**  
10AX 1 Gang Intermediate Switch

PACK: 80pcs 7



**E-K20**  
10AX 2 Gang Intermediate Switch

PACK: 80pcs 8



**E3-BK1A E3-BK1B**  
10AX 1 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 9



**E3-BK12A E3-BK2B**  
10AX 2 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 10




**E3-BK3A E3-BK3B**  
10AX 3 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 11



**E3-BK4A E3-BK4B**  
10AX 4 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 12



**E-P01**  
Single Blank Plate

PACK: 200pcs 13



**E-K45 E-K46**  
5A / 13A Fuse Switch

PACK: 80pcs 14



**E-K30**  
20A Double Pole Switch with Neon

PACK: 80pcs 15



**E-K50-2**  
45A Double Pole Switch with LED Indicator

PACK: 80pcs 16



**E-C11**  
13A BS Socket

PACK: 80pcs 17



**E-C29-3**  
13A BS Socket with Switch

PACK: 80pcs 18



**E-C12-3**  
13A BS Socket with Switch & LED Indicator

PACK: 80pcs 19



**E-C31-2**  
13A BS Socket with DP Switch

PACK: 80pcs 20




**E-C32-2**  
13A BS Socket with DP Switch & LED Indicator  
PACK: 80pcs 21



**E3-C29E16**  
13A BS Switched Socket with 2.1A USB Charger  
PACK: 60pcs 22



**E3-C31E16**  
13A Double Pole BS Switched Socket with 2.1A USB Charger  
PACK: 60pcs 23



**E-JAC28**  
16A 1 Gang Euro-American Socket with Switch  
PACK: 80pcs 24



**E3-E31**  
20W Type A+C USB Charger  
PACK: 60pcs 41



**E3-E33**  
65W Type A+C USB Charger  
PACK: 60pcs 42



**E3-P37**  
45A Flex Outlet  
PACK: 60pcs 43



**E3-P38**  
25A Flex Outlet  
PACK: 80pcs 44



**E3-C28K**  
16A Switched Euro & American Socket  
PACK: 80pcs 25



**E3-C28E24**  
16A Euro & American Socket with 2 Ports USB Charge  
PACK: 60pcs 26



**E3-C28E32**  
16A Euro & American Socket with Type A+C USB Charge  
PACK: 60pcs 27



**E-C18-2**  
16A 2P + E German Socket  
PACK: 80pcs 28



**E-E01**  
Single Telephone Socket  
PACK: 80pcs 45



**E-E02**  
Single Computer Socket  
PACK: 80pcs 46



**E-E03**  
Single TV Socket  
PACK: 80pcs 47



**E-2E01**  
Double Telephone Socket  
PACK: 80pcs 48



**E-C22-2**  
16A 2P+E French Socket  
PACK: 80pcs 29



**E-C23-2**  
16A 2P European Socket  
PACK: 80pcs 30



**E-C17-2**  
15A 3 Round Pin Socket with Switch  
PACK: 80pcs 31



**E-C38**  
15A 3 Round Pin Switched Socket with LED Indicator  
PACK: 80pcs 32



**E-2E02**  
Double Computer Socket (CAT.6)  
PACK: 80pcs 49



**E-E0102**  
Telephone & Computer Socket (CAT.6)  
PACK: 80pcs 50



**E-2E03**  
Double TV Socket  
PACK: 80pcs 51



**E-E06**  
Single Satellite Socket  
PACK: 80pcs 52



**E-C06**  
16A 2 Pin & 3 Pin Universal Socket  
PACK: 80pcs 33



**E-C36**  
16A 3 Pin Universal Socket with Switch  
PACK: 80pcs 34



**E-C37**  
16A 3 Pin Universal Switched Socket with LED Indicator  
PACK: 80pcs 35



**E3-C45**  
16A Switched Universal Socket with Night Light  
PACK: 80pcs 36



**E-E0608**  
TV & Satellite Socket  
PACK: 80pcs 53



**E-E0103**  
Telephone & TV Socket  
PACK: 80pcs 54



**E-E0203**  
Computer & TV Socket  
PACK: 80pcs 55



**E-E0206**  
Computer & Satellite Socket (CAT6)  
PACK: 80pcs 56



**E3-C06E29**  
16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger  
PACK: 60pcs 37



**E3-C06E24**  
16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger  
PACK: 60pcs 38



**E3-C06E32**  
2 Pin & 3 Pin Universal Socket with Type A+C USB Charger  
PACK: 60pcs 39



**E3-E24-2**  
3.1A Double USB Charger  
PACK: 60pcs 40



**E-2E07**  
2 Gang Speaker Outlet  
PACK: 80pcs 57



**E-K22 E-K24**  
Background/General Speaker Voice Dimmer Switch  
PACK: 60pcs 58



**E-K09**  
300W Light Dimmer Switch  
PACK: 60pcs 59



**E-K10**  
630W Light Dimmer Switch  
PACK: 60pcs 60





**E-K86**  
1000W Two Way Push Dimmer Switch  
PACK: 60pcs 71



**E3-2K100**  
Twin 100W LED Dimmer Switch  
PACK: 60pcs 72



**E-K11**  
300W Fan Dimmer Switch  
PACK: 60pcs 73



**E3-K88**  
300W Two Way Push Fan Dimmer Switch  
PACK: 60pcs 74



**E-K44**  
16A High Frequency KeyCard Switch  
PACK: 60pcs 91



**E3-K96**  
"DO NOT DISTURB" Switch  
PACK: 80pcs 92



**E3-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch  
PACK: 80pcs 93



**E3-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch  
PACK: 80pcs 94



**E3-K93**  
100W Step Fan Dimmer Switch  
PACK: 40pcs 75



**E-K12**  
Air Control Dimmer Switch  
PACK: 60pcs 76



**E3-K01BK09**  
300W Light Dimmer With Two Way Rocker Switch  
PACK: 60pcs 77




**E3-K01BK11**  
300W Fan Dimmer With Two Way Rocker Switch  
PACK: 60pcs 78



**E-C34**  
3X3 Shaver Socket  
PACK: 16pcs 95



**E-C08**  
3X6 Shaver Socket  
PACK: 10pcs 96



**E-C13**  
13A Twin BS Socket  
PACK: 50pcs 97



**E-C30-2**  
13A Twin BS Socket with Switch  
PACK: 50pcs 98



**E-K25**  
65-100W Voice Activated & Light Sensor Switch with Time Delay  
PACK: 80pcs 79



**E-K26**  
65-100W Touch Switch with Time Delay  
PACK: 80pcs 80



**E-K23**  
65-100W PIR Switch  
PACK: 60pcs 81



**E-K85**  
PIR Foot Light  
PACK: 80pcs 82



**E-C14-2**  
13A Twin BS Socket with Switch & LED Indicator  
PACK: 50pcs 99



**E-C39**  
13A Twin BS Socket with DP Switch  
PACK: 50pcs 100



**E-C40**  
13A Twin BS Socket with DP Switch & LED Indicator  
PACK: 50pcs 101




**E3-C30E24**  
13A Twin Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 102



**E-K36**  
LED Foot Light  
PACK: 60pcs 83



**E-K37**  
1W Buzzer  
PACK: 80pcs 84



**E-K31**  
3A Alarm Switch  
PACK: 80pcs 85



**E-K17**  
4A Bell Switch with "DO NOT DISTURB" Indicator  
PACK: 80pcs 86



**E3-C14E24**  
13A Twin Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 103



**E3-C39E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 104



**E3-C40E24**  
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 105



**E3-C43**  
16A Twin Universal Switched Socket  
PACK: 50pcs 106



**E-K18**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator  
PACK: 80pcs 87



**E-K21**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator  
PACK: 80pcs 88




**E-K15**  
16A KeyCard Switch  
PACK: 60pcs 89



**E-K43**  
16A Low Frequency KeyCard Switch  
PACK: 60pcs 90



**E3-C43E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger  
PACK: 40pcs 107



**E3-C44**  
16A Twin Universal Switched Socket with Neon  
PACK: 50pcs 108



**E3-C44E24**  
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon  
PACK: 40pcs 109




**E-C26**  
45A Cooker Unit  
PACK: 50pcs 110




**E3-K90**  
147 45A DP Switch

PACK: 50pcs 111




**E-P28**  
Double Blank Plate

PACK: 160pcs 112



**E-K74A E-K74B**  
10AX 147 4 Gang Switch

PACK: 50pcs 113



**E-K75A E-K75B**  
10AX 147 5 Gang Switch

PACK: 50pcs 114

# B3 SERIES

- Classic exterior design
- Complete functional series
- Cost-effective series








**A30-BK01A A30-BK01B**  
16AX 1 Gang Switch Rocker

PACK: 100pcs 1




**A30-BK02A A30-BK02B**  
16AX 2 Gang Switch Rocker

PACK: 100pcs 2




**A30-BK03A A30-BK03B**  
16AX 3 Gang Switch Rocker

PACK: 100pcs 3



**A30-K04A A30-K04B**  
10AX 4 Gang Switch Rocker

PACK: 100pcs 4




**A30-C28K**  
16A Switched Euro & American Socket

PACK: 100pcs 21



**A30-C28E24**  
16A Euro & American Socket with 2 Ports USB Charge

PACK: 80pcs 22



**A30-C28E32**  
16A Euro & American Socket with Type A+C USB Charge

PACK: 80pcs 23




**A30-C18-2**  
16A 2P + E German Socket

PACK: 100pcs 24



**A-K16**  
16A Doorbell Switch

PACK: 100pcs 5



**A-K16**  
16A 1 Gang Retractive Switch

PACK: 100pcs 6



**A30-K19**  
10AX 1 Gang Intermediate Switch

PACK: 100pcs 7




**A30-K20**  
10AX 2 Gang Intermediate Switch

PACK: 100pcs 8




**A30-C22-2**  
16A 2P+E French Socket

PACK: 100pcs 25



**A30-C23-2**  
16A 2P European Socket

PACK: 100pcs 26




**A30-C17-2**  
15A 3 Round Pin Socket with Switch

PACK: 100pcs 27



**A30-C38**  
15A 3 Round Pin Switched Socket with LED Indicator

PACK: 100pcs 28



**A30-P01**  
Single Blank Plate

PACK: 200pcs 9



**A30-K45 A30-K46**  
5A / 13A Fuse Switch

PACK: 100pcs 10




**A30-K30**  
20A Double Pole Switch with Neon

PACK: 100pcs 11




**A30-K50-2**  
45A Double Pole Switch with LED Indicator

PACK: 100pcs 12




**A30-C06**  
16A 2 Pin & 3 Pin Universal Socket

PACK: 100pcs 29



**A30-C36**  
16A 3 Pin Universal Socket with Switch

PACK: 100pcs 30




**A30-C37**  
16A 3 Pin Universal Switched Socket with LED Indicator

PACK: 100pcs 31




**A38-C45**  
16A Switched Universal Socket with Night Light

PACK: 80pcs 32



**A30-C11-2**  
13A BS Socket

PACK: 100pcs 13




**A30-C29-3**  
13A Single Switch Socket

PACK: 100pcs 14




**A30-C12-3**  
13A Single Switch Socket with Neon

PACK: 100pcs 15



**A30-C31-2**  
13A BS Socket with DP Switch

PACK: 100pcs 16



**A30-C06E29**  
2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger

PACK: 80pcs 33



**A30-C06E24**  
16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger

PACK: 80pcs 34



**A30-C06E32**  
2 Pin & 3 Pin Universal Socket with Type A+C USB Charger

PACK: 80pcs 35



**A30-E24-2**  
3.1A Double USB Charger

PACK: 80pcs 36



**A30-C32-2**  
13A BS Socket with DP Switch & LED Indicator

PACK: 100pcs 17



**A30-C29E16**  
13A BS Switched Socket with 2.1A USB Charger

PACK: 80pcs 18



**A30-C31E16**  
13A Double Pole BS Switched Socket with 2.1A USB Charger

PACK: 80pcs 19



**A30-JAC28 A30-JBC28**  
16A 2 Pin Universal Socket with Switch

PACK: 100pcs 20



**A30-E31**  
20W Type A+C USB Charger

PACK: 80pcs 37



**A30-E33**  
65W Type A+C USB Charger

PACK: 80pcs 38



**A30-P37**  
45A Flex Outlet

PACK: 80pcs 39




**A30-P38**  
25A Flex Outlet

PACK: 100pcs 40



**A30-E01**  
Single Telephone Socket

PACK: 100pcs 41




**A30-E02**  
Single Computer Socket

PACK: 100pcs 42



**A30-E03**  
Single TV Socket

PACK: 100pcs 43



**A30-2E01**  
Double Telephone Socket

PACK: 100pcs 44



**A30-K93**  
100W Step Fan Dimmer Switch

PACK: 60pcs 61



**A30-K12**  
Air Control Dimmer Switch

PACK: 80pcs 62




**A30-K01BK09**  
300W Light Dimmer With Two Way Rocker Switch

PACK: 80pcs 63




**A30-K01BK11**  
300W Fan Dimmer With Two Way Rocker Switch

PACK: 80pcs 64




**A30-2E02**  
Double Computer Socket (CAT.6)

PACK: 100pcs 45



**A30-E0102**  
Telephone & Computer Socket (CAT.6)

PACK: 100pcs 46



**A30-2E03**  
Double TV Socket

PACK: 100pcs 47




**A30-E06**  
Single Satellite Socket

PACK: 100pcs 48



**A30-K25**  
65-100W Voice Activated & Light Sensor Switch with Time Delay

PACK: 100pcs 65



**A30-K26**  
65-100W Touch Switch with Time Delay

PACK: 100pcs 66



**A30-K23**  
65-100W PIR Switch

PACK: 80pcs 67



**A30-K85**  
PIR Foot Light

PACK: 100pcs 68



**A30-E0608**  
TV & Satellite Socket

PACK: 100pcs 49



**A30-E0103**  
Telephone & TV Socket

PACK: 100pcs 50



**A30-E0203**  
Computer & TV Socket (CAT.6)

PACK: 100pcs 51



**A30-E0206**  
Computer & Satellite Socket (CAT.6)

PACK: 100pcs 52




**A30-K36**  
LED Foot Light

PACK: 80pcs 69



**A30-K37**  
1W Buzzer

PACK: 100pcs 70



**A30-K31**  
3A Alarm Switch

PACK: 100pcs 71



**A30-K17**  
4A Bell Switch with "DO NOT DISTURB" Indicator

PACK: 100pcs 72



**A30-2E07**  
2 Gang Speaker Outlet

PACK: 100pcs 53



**A30-K22 A30-K24**  
Background/General Speaker Voice Dimmer Switch

PACK: 80pcs 54



**A30-K09**  
300W Light Dimmer Switch

PACK: 80pcs 55



**A30-K10**  
630W Light Dimmer Switch

PACK: 80pcs 56




**A30-K18**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator

PACK: 100pcs 73




**A30-K21**  
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator

PACK: 100pcs 74



**A30-K15**  
16A Key card Switch

PACK: 80pcs 75



**A30-K43**  
16A Low Frequency Key Card Switch

PACK: 80pcs 76



**A30-K86**  
1000W Two Way Push Dimmer Switch

PACK: 60pcs 57



**A30-2K100**  
Twin 100W LED Dimmer Switch

PACK: 80pcs 58



**A30-K11**  
300W Fan Dimmer Switch

PACK: 80pcs 59



**A30-K88**  
300W Two Way Push Fan Dimmer Switch

PACK: 60pcs 60



**A30-K44**  
16A High Frequency Key Card Switch

PACK: 80pcs 77



**A30-K96**  
"DO NOT DISTURB" Switch

PACK: 100pcs 78



**A30-K97**  
"DO NOT DISTURB" & "MAKE UP ROOM" Switch

PACK: 100pcs 79



**A30-K98**  
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch

PACK: 100pcs 80




**Accessories**



**A30-C34**  
10VA 115V- / 10A 230V-  
Shaver Socket  
PACK:16 pcs 81



**A38-C08**  
Shaver Socket  
PACK: 10pcs 82



**A38-C13**  
13A Twin BS Socket  
PACK: 70pcs 83



**A38-C30**  
13A Twin Switched Socket  
PACK: 70pcs 84



**A30-P02**  
Water Proof  
PACK:39 pcs 1




**86-P15**  
Mounting Box  
PACK:240 pcs 2



**A77-P30**  
IP56 Water Proof Box  
PACK: 50pcs 3



**A38-C14**  
13A Twin Socket with switch  
& LED Indicator  
PACK: 70pcs 85



**A38-C39**  
13A DP Twin Switched Socket  
PACK: 70pcs 86



**A38-C40**  
13A DP Twin Socket with switch  
& LED Indicator  
PACK: 70pcs 87



**A38-C30E24**  
13A Twin Switched Socket with  
2 Ports USB Charger  
PACK: 40pcs 88



**BS-P14-25**  
0.8mm 3X3 BS Metal wall  
mounting box 25mm depth  
PACK: 100pcs 4



**BS-P14-35**  
0.8mm 3X3 BS Metal wall  
mounting box 35mm depth  
PACK: 100pcs 5



**BS-P14-47**  
0.8mm 3X3 BS Metal wall  
mounting box 47mm depth  
PACK: 100pcs 6




**A38-C14E24**  
13A Twin Switched Socket with  
2 Ports USB Charger & Neon  
PACK: 40pcs 89



**A38-C39E24**  
13A Twin DP Switched Socket  
with 2 Ports USB Charger  
PACK: 40pcs 90



**A38-C40E24**  
13A Twin DP Switched Socket  
with 2 Ports USB Charger & Neon  
PACK: 40pcs 91



**A38-C43**  
16A Twin Universal Switched  
Socket  
PACK: 60pcs 92



**BS-2P14-25**  
0.8mm 3X6 BS Metal wall  
mounting box 25mm depth  
PACK: 100pcs 7




**BS-2P14-35**  
0.8mm 3X6 BS Metal wall  
mounting box 35mm depth  
PACK: 100pcs 8



**BS-2P14-47**  
0.8mm 3X6 BS Metal wall  
mounting box 47mm depth  
PACK: 100pcs 9



**A38-C43E24**  
16A Twin Universal Switched Socket  
with 2 Ports USB Charger  
PACK: 40pcs 93



**A38-C44**  
16A Twin Universal Switched Socket  
with Neon  
PACK: 60pcs 94



**A38-C44E24**  
16A Twin Universal Switched Socket  
with 2 Ports USB Charger & Neon  
PACK: 40pcs 95



**A38-C26**  
45A Cooker Unit  
PACK: 60pcs 96



**YWMD-BX-C06**  
2&3 Pin Universal Floor  
Socket (SS)  
PACK: 10pcs 10



**YWMD-BX-2C06**  
Double 3 Pin Universal Floor  
Socket (SS)  
PACK: 10pcs 11



**YWMD-BX-C06E16**  
3 Pin Universal with USB Floor  
Socket (SS)  
PACK: 10pcs 12



**YWMD-BX-E0116**  
Telephone with USB Floor  
Socket (SS)  
PACK: 10pcs 13



**A38-K90**  
147 45A DP Switch  
PACK: 60pcs 97



**A38-P28**  
Double Blank  
PACK: 140pcs 98



**YWMD-BX-E0203**  
Computer with TV Floor  
Socket (SS)  
PACK: 10pcs 14



**YWMD-BX-E01C06**  
3 Pin Universal with Telephone  
Floor Socket (SS)  
PACK: 10pcs 15



**YWMD-FT-C06**  
2&3 Pin Universal Floor  
Socket (GD)  
PACK: 10pcs 16



**YWMD-FT-C02E0222**  
2 Pin with Computer with  
HDMI Floor Socket (GD)  
PACK: 10pcs 17

## Mini Circuit Breaker / Residual Current Circuit Breaker



**JDM60-1P**  
1P Mini Circuit Breaker  
10A-63A  
PACK: 240pcs 18



**JDM60-2P**  
2P Mini Circuit Breaker  
10A-63A  
PACK: 120pcs 19



**JDM60-3P**  
3P Mini Circuit Breaker  
10A-63A  
PACK: 80pcs 20



**JDM60-4P**  
4P Mini Circuit Breaker  
10A-63A  
PACK: 60pcs 21



**JDMR60-1P+N**  
1P+N Residual Current Circuit  
Breaker 10A-63A  
PACK: 80-100pcs 22



**JDMR60-2P**  
2P Residual Current Circuit  
Breaker 10A-63A  
PACK: 60pcs 23



**JDMR60-3P+N**  
3P+N Residual Current Circuit  
Breaker 10A-63A  
PACK: 40pcs 24



**JDMR-4P**  
4P Residual Current Circuit  
Breaker 10A-63A  
PACK: 20-40pcs 25